Jacket With Gathered Peplum - Выкройка #2850



Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: fusible interfacing; shoulder pads; 4 hooks and eyes.

Seam allowances: all seams 1 cm. Seam allowance along the hem of the jacket – 2 cm. Seam allowance on lower edge of sleeve - 3 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Upper back – cut 2
2. Lower back – cut 1 on fold
3. Front – cut 2
4. Placket – cut 1
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2
7. Stand collar – cut 2

8. Back neck facing – cut 1
9. Center front facing – cut 2

Fusible interfacing:
1. Placket – cut 1
2. Center front facing – cut 2
3. Back neck facing – cut 1
4. Stand collar – cut 1

Инструкции:

1. Apply fusible interfacing.

2. Sew darts on back, shorten the bulk of the darts to 1 cm, press towards center and serge. Sew the center back seam, press towards left and serge.

3. Sew a gathering stitch along the upper edge of lower back and gather fullness. Sew upper back to lower back, press towards top and serge.

4. Cut away the bulk of the darts on fronts, leaving 1 cm. Sew darts, press bulk towards center, serge.

5. Sew a gathering stitch along the upper edge of the 1-piece peplum on the front and gather fullness. Sew upper front to lower front, press towards top, serge.

6. Sew shoulder and side seams, press towards the back, serge.

7. Pin together parts of stand collar, right sides together and sew the ends and the upper edge. Trim away corners, clip into curves, turn stand collar right side out, straighten, press. Sew the stand collar into neckline.

8. Fold placket in half lengthwise right sides together and sew short sides. Turn right side out placket onto right side, straighten, press.

9. Sew side seams of back neckline facing and central front facings, press seam apart. Serge the outer edge. Pin center front facings onto the main piece right sides together and sew center front edge, neckline and lower edge, inserting the placket and the loops in between the left center front facing and the front. Trim away corners, clip into curves, fold center front facings and neckline facing onto wrong side, straighten, press. Sew the facing to the shoulder seams and to the center back seams by hand.

10. Sew the elbow seam and the front seam on the sleeve, press the seam allowances towards the upper part, serge. Sew sleeves into armholes matching notches, adjusting ease along upper side of sleeve cap, serge and press. Sew shoulder pads.

11. Serge the seam allowances for hem of garment and hem of sleeve, fold inside onto wrong side and

topstitch.

12. Sew the hooks on the right front according to the eyelets.

Технический рисунок:

