Linen Blouse With Gathers At Neckline - Выкройка #2853

Recommendations on fabric: linen mixed/natural fabrics.

You will also need: fusible interfacing, 1 button.



Seam allowances: all seams 1 cm. Seam allowance along the lower edge of the garment – 2 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back - cut 2
2. Front – cut 1 on fold
3. Back neck facing – cut 4
4. Front neck facing – cut 2

Fusible interfacing:
1. Back neck facing – cut 2

2. Front neck facing – cut 1

Инструкции:

1. Apply fusible interfacing.

2. Serge the center back edges separately. Sew center edge from the marking for slit down to the lower edge. Press the seam apart. Sew a decorative stitch along the slit at 0.2 cm from the edge.

3. Sew a gathering stitch along front neckline between notches and gather fullness. Sew the front facing to front. Press the seam allowances towards the facing.

4. Sew the back facing to the back. Clip seam allowances and press towards facing.

5. Sew shoulder seams. Press seams towards back and serge.

6. Cut or use ready-made bias tape, its width should equal 4 cm and length should equal the length of armhole + 5 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape onto armhole edge from the right side and sew. Clip into seam allowances. Fold bias tape onto wrong side and topstitch onto main piece along the fold. Press seam.

7. Sew side seams, press towards the back and serge.

8. Cut (or take ready) bias tape, its width should equal 2.5 cm and its length should equal 10 cm for loop buttonhole. Fold tape in half lengthwise right sides together and stitch at 0.3 cm from fold. Cut away seam allowances close to seam, turn tape right side out and straighten the rolled piece. Adjust length of the loop.

9. Sew shoulder seams of facings. Press the seam apart. Serge the outer edge.

10. Pin the inner facing onto front, sew the neckline opening and center back edges, inserting the loop buttonhole. Clip seam allowances, fold facing onto wrong side and press. Topstitch the inner facing into the seam of the outer facing.

11. Serge hem of garment, press onto wrong side and topstitch.

12. Sew a button onto the back facing.

Технический рисунок:



