

Blouse With Buttons - Выкройка #2855

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing; 6 buttons.

Seam allowances: all seams 1 cm. Seam allowance along the lower edge of the garment – 2 cm. Seam allowance on lower edge of sleeve – 1.2 cm.

О припусках на швы::

- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:

Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.



РАСКРОЙ:

Обратите внимание при раскрое:

Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроются со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.

При стачивании деталей, обращайтесь внимание на надсечки, они должны совпадать.

Main fabric:

1. Back – cut 2
2. Front – cut 2
3. Sleeve – cut 2
4. Collar – cut 2

Fusible interfacing:

1. Collar – cut 1

Инструкции:

1. Apply fusible interfacing. Apply fusible interfacing to the inner one-piece placket.
2. Sew dart on back. Trim bulk to 1 cm and press towards the center. Sew center back seam. Serge seam and press towards left.
3. Sew dart on front. Trim bulk to 1 cm, press towards center.
4. Clip into seam allowance of the front neckline near center mark. Sew upper corner of front piece. Trim away the seam allowance, fold the inner placket onto wrong side and press the fold. Fold inside the unfinished edge of the inner placket and topstitch.
5. Sew shoulder seams, press towards the back, serge.
6. Pin collars together, right sides together, and sew the ends and the outer edge of collar. Start and stop sewing exactly at the marked line of the seam between collar and garment. Trim away corners, turn the collar right side out, straighten and press. Sew outer collar into neckline, turn under raw edge of inner collar and stitch in the ditch.
7. Serge lower edge of sleeve, fold inside onto wrong side and topstitch. Sew a gathering stitch along upper edge of sleeve cap gather fullness. Sew sleeve into armhole. Serge.
8. Sew side seams, press towards the back and serge.
9. Cut or use ready-made bias tape, its width should equal 4 cm and length should equal the length of lower armhole + 4 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape onto armhole edge from the right side and sew. Fold bias tape onto wrong side and topstitch onto main piece along the fold. Press seam.
10. Serge the lower edge of garment, press onto wrong side and topstitch.
11. Make buttonholes on right front, sew on buttons on the left one.

Технический рисунок:

