

## Dress With Decorative Seams - Выкройка #2874

Recommendations on fabric: natural/mixed fabric suitable for dresses.

You will also need: fusible interfacing; dress zipper.

Seam allowances: all seams 1 cm; seam allowance for hem of dress and hem of sleeve - 2.5 cm.

### О припусках на швы::

- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.

- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

### О требуемой длине ткани:

**Внимание!** В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.



## РАСКРОЙ:

### Обратите внимание при раскрое:

Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроются со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.

При стачивании деталей, обращайтесь внимание на надсечки, они должны совпадать.

Main fabric:

1. Upper back - cut 2
2. Lower center back - cut 2
3. Lower side back - cut 2
4. Upper center front - cut 1
5. Upper side front - cut 2
6. Lower center front - cut 1 on fold
7. Lower side front - cut 2

8. Sleeve - cut 2
9. Collar - cut 2

Fusible interfacing:

1. Collar - cut 2

## **Инструкции:**

1. Apply fusible interfacing.
2. Sew darts on upper back, press bulk towards center. Sew princess seams of lower back (sew side backs to center back). Serge seams and press towards center. Sew upper back to lower back, press seam allowances towards top and serge.
3. Serge the center back edges separately. Sew the center back seam from zipper mark to hem, press the seam apart. Sew in zipper.
4. Sew darts on upper side fronts, press bulk towards top. Sew upper side fronts to upper central front. Serge the seam allowances, press towards top.
5. Sew lower side fronts to central side front. Serge seams and press towards center.
6. Sew upper front to lower front, snipping into the corner of the lower front, press seam allowances towards top and serge.
7. Sew shoulder and side seams, press seam allowances towards back and serge.
8. Pin the collars together, right sides together and sew collar ends and the outer edge of collar, start and stop stitching exactly at the marked line of the seam. Clip into curves, trim away corners. Turn collar right side out, straighten, press. Sew the upper collar into the neckline, clip seam allowances, press towards collar. Fold inside seam allowance of inner collar and topstitch into seam of.
9. Sew sleeve seam, press towards the back and serge. Sew sleeves into armholes, matching notches, serge and press.
10. Serge hem of dress and hem of sleeve, press onto wrong side and finish with hidden stitches.

## **Технический рисунок:**

