

Flared Blouse - Выкройка #2893

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing; 5 buttons.

Seam allowances: all seam allowances - 1 cm. Seam allowance for hem of garment - 2.0 cm.

О припусках на швы::

- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.

- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:

Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.



РАСКРОЙ:

Обратите внимание при раскрое:

Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроются со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.

При стачивании деталей, обращайтесь внимание на надсечки, они должны совпадать.

Main fabric:

1. Back - cut 1 on fold
2. Front right - cut 1
3. Front left - cut 1
4. Collar - cut 2
5. Cuff - cut 4
6. Placket - cut 1
7. Stand collar - cut 2

Fusible interfacing:

1. Collar - cut 1
2. Placket - cut 1
3. Stand collar - cut 2

Attention! Pattern blocks have markings and texts from the right side. Take this into account when cutting the fabric-some of the pattern blocks need to be laid onto fabric with their wrong side on top.

Инструкции:

1. Apply fusible interfacing. Apply fusible interfacing to the buttonhole area of the integrated placket.
2. Finishing the left front edge: Placket press in half lengthwise right side out. Sew the placket to the left front, serge and press towards the main piece.
Finishing the right front edge: Serge the outer edge. Press the placket to the wrong side along line 3. Make buttonholes. Press the placket along the front edge line, matching it with line 3. Sew a decorative securing stitch along the front edge at the width of the placket.
3. Sew shoulder seams, press towards the back and serge.
4. Pin upper collar to lower collar, right sides together, sew ends of collar and collar fall. Trim seam allowances, turn the collar right side out, straighten and press. Pin stand collars together, right sides together, put ready collar between them, adjust notches and sew, sewing ends of stand collar at the same time. Start and stop sewing exactly at the marked line of seam between stand collar and garment. Turn finished collar right side out and press. Sew upper stand collar with collar into neckline, fold raw edge of lower stand collar and stitch-in-the-ditch along seam of upper stand collar.
5. Sew cuffs into a ring, press the seam apart. Pin together cuffs pairwise right sides together and sew lower edge. Clip seam allowances, turn right side out and press.
6. Sew side seams, press towards the back and serge.
7. Sew cuffs to sleeve, serge and press towards the main piece.
8. Press lower edge of garment onto wrong side at 1 cm, then again at 1 cm and topstitch.
9. Sew on buttons onto the left front edge.

Технический рисунок:

