Blouse With Flounces - Выкройка #2896



Recommendations on fabric: thin well draping natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing; dress zipper; elastic thread.

Seam allowances: all seams 1 cm. Seam allowance along the lower edge of the garment – 2 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back - cut 2
2. Front – cut 2
3. Sleeve – cut 2
4. Front flounce – cut 2
5. Back flounce — cut 1
6. Front neck facing – cut 1
7. Back neck facing — cut 1

Fusible interfacing:
1. Front neck facing – cut 1
2. Back neck facing — cut 1

Инструкции:

1. Apply fusible interfacing.

2. Sew darts on back and front. Press bulk of waist darts towards center, press bulk of bust darts towards top.

3. Serge the center back edges separately. Sew the center back edges from the neckline edge to the first mark and from the second mark to the lower edge, press the seam apart. Sew in zipper.

4. Sew shoulder seams, press towards the back and serge.

5. Sew shoulder edges of flounces, press the seam apart and serge. Serge the outer edge of the flounces, press onto wrong side and topstitch. Alternatively, the outer edge can be finished with a narrow rolled hem (trim the seam allowance before finishing) . Clip the inner seam allowances of the front flounces at the mark, place them wrong side to the right side of the front, and secure them along the neckline edges and the center front edges.

6. Sew center seam on front, press the seam apart and serge.

7. Sew side seams, press towards the back and serge.

8. Sew shoulder seam on front neckline facing and back neckline facing, press the seam apart. Serge the outer edge. Pin facings to garment right sides together and sew the front neckline and the back neckline. Clip the seam allowances on the curves and at the corner of the front, turn facing onto wrong side, straighten, press. Secure to the garment along the shoulder seams and center seams.

9. Sew sleeve seam, serge and press. Sew a gathering stitch along the sleeve cap and gather fullness. Serge lower edge of sleeve, press onto wrong side and topstitch. (The lower edge of the sleeve can also be finished with a narrow rolled hem. Before doing so, trim the seam allowance of the lower edge.) Sew along the marked line using elastic thread.

10. Sew sleeves into armholes, serge and press.

11. Serge hem of garment, press onto wrong side and topstitch.

Технический рисунок:



