

Jacket With Shaped Collar - Sewing Pattern #4005

Recommendations on fabric: soft woollen / half woollen fabrics (soft gabardine).

You will also need: fusible interfacing; 3 button; lining; shoulder pads.

Seam allowances: all seams 1 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.



Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

- 1. Lower collar cut 1
- 2. Upper collar cut 1
- 3. Side front cut 2
- 4. Side back cut 2
- 5. Center back cut 2
- 6. Center front cut 2
- 7. Center front facing cut 2
- 8. Back neck facing cut 1
- 9. Back belt cut 2
- 10. Front belt cut 4



- 11. Sleeve cut 2
- 12. Cuff cut 2

Lining:

- 1. Center front cut 2
- 2. Side back cut 2
- 3. Center back cut 2
- 4. Side front cut 2
- 5. Sleeve cut 2

Fusible interfacing:

- 1. Center front cut 2
- 2. Center front facing cut 2
- 3. Back neck facing cut 1
- 4. Back belt cut 1
- 5. Front belt cut 2
- 6. Cuff cut 2
- 7. Upper collar cut 1

INSTRUCTIONS:

- 1. Apply fusible interfacing. Apply fusing on front along the lapel fold , its width should equal 1 cm (fusible interfacing).
- 2. Sew princess seams on front and back (sew side parts to center parts) and press towards center. Sew a decorative stitch at 0.9 cm from seam.
- 3. Sew and press apart center edge of back. Sew and press apart shoulder and side edges of jacket.
- 4. Sew together the front belts and the back belts, pairwise. Press seams apart. Sew the belts with fusible interfacing to the jacket. Press seams apart.
- 5. Sew and press the sleeve seam apart. Sew cuffs into a ring. Шов press apart. Cuffs turn right side out, press in half lengthwise and sew its outer edge to lower edge of sleeve. Шов press apart.
- 6. Sew sleeves into armholes matching notches, adjusting ease on sleeve cap. Sew shoulder pads.
- 7. Pin upper collar to lower collar and sew. Trim corners, turn right side out, straighten and press collar.
- 8. Sew seams on lining and sew in sleeves, leaving an opening in the right sleeve seam.
- 9. Sew and press apart the shoulder edges of the back neckline facing and of the center front facing. Sew lining to inner edges of the central front facings and to back neckline facing. Sew belts to the lower edge of lining.



Press towards belt.

- 10. Pin center front facing onto front right sides together, pin together and sew center front edge. When stitching make sure to place the front piece on top, sew from bottom towards top up to notch, that marks the end of collar seam. Trim seam allowances on the corners of upper lapels.
- 11. Sew lower collar into neckline of Shell, sew upper collar into back neckline facing and center front facing. Press seam allowances of the collar seam apart and slipstitch them together close to the seam.
- 12. Sew lower edge of garment. Turn the jacket right side out, straighten seams and press. Sew a decorative fixing stitch into the belt seam. Sew a decorative stitch at 1 cm from the edge along the center front edge, of collar and of the lower edge of jacket.
- 13. Sew lining to the inner edge of cuff. Press towards cuff. Turn jacket right side out through the opening in seam. Sew the opening in the sleeve closed. Sew a decorative fixing stitch into seam of cuff.
- 14. Make buttonholes on right front, and sew on buttons onto left front.

TECHNICAL DRAWING:



