Dress With Collar - Sewing Pattern #4414

Recommendations on fabric: natural/mixed fabric suitable for dresses, contrasting natural/mixed fabric suitable for dresses.



You will also need: dress zipper, 9 buttons.

Seam allowances: all seam allowances 1 cm; seam allowance for hem of sleeve — 1.5 cm.

Note on seam allowances:
- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:
Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

CUTTING:

Note on cutting:
On the pattern pieces, “beam” means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.
When sewing the garment, pay attention to notches, they must match up.

Main fabric:
1. Upper back - cut 2
2. Lower back - cut 2
3. Upper front - cut 1
4. Lower center front - cut 1
5. Lower left front — cut 1
6. Lower right front — cut 1
7. Sleeve — cut 2

Main fabric 2:
1. Back flounce — cut 1
2. Front flounce - cut 1.
3. Right collar — cut 2
4. Left collar — cut 2

Fusible interfacing:
1. Right collar — cut 1
2. Left collar — cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.

2. Sew darts on upper backs and lower backs. Press darts towards center. Sew upper back to lower back. Serge and press towards bottom. Serge center back edges separately. Sew center back seam from zipper marker down to hem, press the seam apart. Sew in zipper.

3. Sew darts on upper fronts. Press darts towards center.

4. Sew side fronts to front. Serge seams and press towards center.

5. Sew flounces to front and back correspondingly. Serge seams and press towards top.

6. Sew shoulder and side seams on backs and fronts. Serge seams and press towards back.

7. Pin upper collar to lower collar, right sides together and sew outer edges. Trim seam allowances, turn collar right side out and press. Clip into seam allowance on neckline near notch. Sew outer collar into neckline. Turn inside seam allowance of inner collar and topstitch into seam of outer collar.

8. Serge bottom edge of sleeve, turn inside and topstitch. Sew sleeves into armholes. Serge the seam allowances. Cut or use ready-made bias tape, its width should equal 4 cm and length should equal the length of lower armhole + 5 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape to armhole edge from the right side and sew. Clip into seam allowances. Fold bias tape onto wrong side and topstitch onto main piece along the fold. Press.

9. Serge bottom edge of garment, press onto wrong side and topstitch. Sew on buttons.

TECHNICAL DRAWING:



