

## Long Jacket - Sewing Pattern #4415

Recommendations on fabric: natural/mixed suiting fabrics.  
You will also need: lining; fusible interfacing; 2 hooks and eyes; 2 push buttons; shoulder pads.

Seam allowances: all seam allowances 1 cm. Seam allowance for hem of garment and seam allowance for hem of sleeve - 3.5 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

*Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.*



## CUTTING:

### Note on cutting:

*On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.*

*When sewing the garment, pay attention to notches, they must match up.*

Main fabric:

1. Center back – cut 2
2. Side back – cut 2
3. Upper front – cut 2
4. Center front – cut 2
5. Lower front – cut 2
6. Upper sleeve – cut 2
7. Lower sleeve – cut 2

8. Back neck facing – cut 2
9. Buttonstand (center front facing) – cut 2
10. Bow — cut 1
11. Strap — cut 1
12. Belt Loop — cut 1

Lining:

1. Center back – cut 2
2. Side back – cut 2
3. Upper front – cut 2
4. Center front – cut 2
5. Lower front – cut 2
6. Upper sleeve – cut 2
7. Lower sleeve – cut 2

Fusible interfacing:

1. Upper front – cut 2
2. Center front – cut 2
3. Lower front – cut 2
4. Buttonstand (center front facing) — cut 2
5. Back neck facing — cut 2

Fusible interfacing is also applied to: seam allowances on back armholes, seam allowance for hem of garment and seam allowance for hem of sleeve.

## INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew shoulder darts on back. Press bulk towards center. Sew side backs to center back, press seam apart. Sew center back seam. Press seam apart.
3. Sew upper front to middle front, press towards top. Sew lower piece to center piece полочки, press seam apart. Make and baste pleats on center front.
4. Sew shoulder seams and seam of wholecut stand collar at the same time. Clip into curves. Press seam apart.
5. Sew side seams. Press seam apart.
6. Sew center seam on back neck facing. Sew shoulder seams of button stands and facings and seam of wholecut stand collar at the same time. Press seam apart.
7. Fold bow lengthwise посередине and sew short sides. Trim away corners. Turn right side out. Make pleats as

desired.

8. Press seam allowance on lower edge. Pin buttonstand onto right side of front, right side down, and sew around center edges and edge of stand collar, inserting bow according to notches (on right front), hooks and eyes. Sew lower edge of buttonstand to front exactly according to the marked line of hem, stepping back from inner size of buttonstand at 1.5 cm. Trim away corners, turn buttonstands and stand collar right side out onto right side, straighten seams.

9. Sew elbow seam on sleeve, press seam apart. Press seam allowance for hem of sleeve. Sew front seam on sleeve, press seam apart. Sew sleeves into armholes. Sew on shoulder pads.

10. Sew seams on lining, leaving an opening in left side seam for turning. Sew sleeves into armholes. Sew lining to buttonstands and facing.

11. Sew lining to lower edge of garment and lower edge of sleeve. Turn garment right side out through the opening. Sew the opening closed.

12. Fold strap in half lengthwise right sides together and sew along long side. Turn piece right side out, straighten, placing seam in the middle of the piece.

13. Serge one long edge on belt loop. Press raw seam inside, covering it by serged edge. Sew a decorative stitch along edge.

14. Pin belt loop onto strap, serge raw edges. Press serged edges onto wrong side, pin the piece onto front and topstitch, covering the seams attaching center front.

15. Sew hidden buttons at bow, sew the other parts of buttons on center front.

## TECHNICAL DRAWING:

