

## Light Coat With Hidden Button Panel - Sewing Pattern #4478

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: lining; fusible interfacing; 5 buttons; shoulder pads.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 3.5 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

*Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.*



## CUTTING:

### Note on cutting:

*On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.*

*When sewing the garment, pay attention to notches, they must match up.*

Main fabric:

1. Back - cut 2
2. Front - cut 2
3. Stand collar - cut 2
4. Upper sleeve - cut 2
5. Lower sleeve - cut 2
6. Back neck facing - cut 1
7. Center front facing - cut 2

Lining:

1. Back – cut 2
2. Front – cut 2
3. Upper sleeve – cut 2
4. Lower sleeve – cut 2
5. Lining of hidden button panel – cut 2

Attention: Lining for back and front is cut using pattern pieces for main fabric except for back neckline facing and central front facings correspondingly.

Fusible interfacing:

1. Front – cut 2
2. Center front facing — cut 2
3. Stand collar – cut 1
4. Back neck facing — cut 1
5. Lining of hidden button panel – cut 1

Fusing interfacing is also applied to seam allowances on back armhole, lower edge of garment and lower edge of sleeve.

## INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on back, press bulk towards center. Apply fusible interfacing to vent areas on the back on the wrong side. Mark center seam line (vent fold-line) from the right side. Press left back along fold line of vent. Align pieces along center seam. Sew center back seam and corner of vent, stop stitching when the distance from vertical edge of vent is 1 cm. Clip into seam allowance of vent in corner on right part. Press apart center seam, press seam allowances of vent and topstitch them from the right side using machine stitch.
3. Sew darts on front, clip into curves and press apart.
4. Sew outer stand collar into back neckline, clip seam allowances and press apart.
5. Sew shoulder seams of coat sewing the stand collar seam at the same time, clip seam allowances and press apart. Sew side seams, press the seam apart.
6. Mark the slit for closure on right side of right central front facing with three lines: first line is parallel to edge of central front facing and is placed at 1.5 cm from the edge of central front facing on ready garment, the second and the third lines mark the length of closure. Pin lining with fusing interfacing applied onto right side of the central front facing, right side down, matching one edge of lining with edge of the central front facing, align edge of lining and marked line. Sew a stitch line at 0.5 cm from marked line along the closure slit up to the lines marking the length of closure. Pin second lining exactly matching the edge of second lining and stitch line

of first lining and sew a stitch line at 0.5 cm. Verify that the stitch lines are parallel from wrong side. Cut the slit for closure. Make slashed cuts at 1-1.5 cm from the end of slit. Turn the lining onto wrong side, making a frame, which equals the distance between stitch lines. Sew a fixing stitch into the seam of the first lining. Iron the second lining towards inner edge of the central front facing and sew a fixing stitch line at 0.1 cm from the seam of lining. Mark and make buttonholes (through all layers of main fabric and linings). Straighten and fix ends of closure from the wrong side with double back stitch at the corners. Sew edges of lining. Sew short fixing stitches between each pair of buttonholes.

7. Sew inner stand collar into neckline facings, clip seam allowances and press apart. Sew shoulder seams of central front facings and facings, continue sewing the seam of stand collars, press the seam apart.

8. Press seam allowance on lower edge. Pin central front facings onto front right sides together, sew central front facings and edge of stand collar. Sew corner of central front facing, stopping before the inner edge of the central front facing at 1.5 cm. Trim away corners, turn central front facings and stand collar right side out onto right side, straighten seams.

9. Sew the elbow seam of the sleeve and press it apart. Press the hem of sleeve. Sew and press apart front sleeve seam. Sew sleeve into armhole. Sew on shoulder pads.

10. Sew seams on lining, leaving an opening in left side seam for turning. Sew pykava. Sew lining to the central front facings and to facing.

11. Sew lining to lower edge of garment, vent and lower edge of sleeve. Turn coat right side out through the opening. Sew the opening closed.

12. Sew a decorative stitch on right front according to markings, fixing in place hidden button panel. Sew on buttons according to button holes.

## TECHNICAL DRAWING:

