

## Coat With Assymmetric Collar - Sewing Pattern #4483

Recommendations on fabric: natural/mixed fabric suitable for coats.

You will also need: fusible interfacing; 5 buttons; lining; shoulder pads.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment 3.5 cm, seam allowance for hem of sleeve — 3 cm, along the edges of pocket bags and off-set welts — 2 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

*Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.*



## CUTTING:

### Note on cutting:

*On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.*

*When sewing the garment, pay attention to notches, they must match up.*

Main fabric:

1. Front – cut 2
2. Back – cut 2
3. Sleeve – cut 2
4. Buttonstand (center front facing) – cut 2
5. Off-set welt – cut 2
6. Back neck facing – cut 1
7. Collar – cut 2

8. Belt – cut 1
9. Cap Of Sleeve — cut 2

Lining:

1. Front – cut 2
2. Back – cut 2
3. Sleeve lining – cut 2
4. Small pocket bag – cut 2
5. Large pocket bag — cut 2

Fusible interfacing: buttonstand (center front facing), off-set welt, back neck facing, upper collar.

Lining is cut using pattern blocks for main fabric except for the width of neckline facing and cap of sleeve.

## INSTRUCTIONS:

1. Apply fusible interfacing to buttonstand (center front facing), back neckline facing, upper collar, armhole edge on front and on back and on cap sleeve. Apply fusible interfacing to pocket opening on front.
2. Apply fusible interfacing to vent areas on the back on the wrong side. Mark center seam line (vent fold-line) from the right side. Press left back along fold line of vent. Align pieces along center seam. Sew center back seam and corner of vent, stop stitching when the distance from vertical edge of vent is 1 cm. Clip into seam allowance of vent in corner on right part. Press apart center seam, press seam allowances of vent and topstitch them from the right side using machine stitch.
3. Sew and press darts on front. Press bulk towards bottom.
4. Mark the position of pocket. Press welt in half lengthwise wrong sides together. Topstitch small pocket bag onto inner side of welt. Sew welt to front along lower marked line of pocket. Sew large pocket bag to front along upper marked line of pocket. Stop stitching near short marking lines of the pocket. Slash through pocket opening. Snip diagonally toward end of stitching at 1-1.5 cm from end of pocket opening. Turn welt and large pocket bag onto wrong side through the resulting opening. Sew a double back stitch lines near corners to fix ends of pockets. Sew together edges of pocket bags.
5. Sew and press apart shoulder and side edges. Sew sleeve cap to front and to back. Press at cap of sleeve.
6. Sew shoulder seams of back neckline facing and buttonstand. Press seams apart.
7. Pin buttonstands and facing right side down onto right side of coat and sew buttonstands to front.
8. Pin collars together, right sides together. Sew ends of collar and collar fall. Turn the collar right side out and press. Sew lower collar into neckline of back and front.

9. Sew in upper collar into neckline of facing and buttonstand. Press seam apart. Baste together seam allowances on collar seams close to stitch line.
10. Sew sleeve seam. Press seam apart. Sew sleeves into armholes matching notches. Sew shoulder pads.
11. Serge and press seam allowance for hem of garment.
12. Sew seams on lining and sew in sleeves.
13. Sew lining to inner edges of buttonstands and to back neckline facing. Sew lining to hem of sleeve. Slash lining near vent and baste together with vent edges. Sew lining to lower edge of garment.
14. Pin together belt in half lengthwise right sides together and sew, leaving an opening. Turn right side out belt through the opening and sew it closed . Sew a decorative stitch around all edges at 0.5 cm from edge.
15. Make buttonholes on right front. Sew on buttons accordingly.

## TECHNICAL DRAWING:

