

Dress With Pleated Neckline - Sewing Pattern #4777

: .

: ; .

: 1 . - 2.0 .

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

:

1. -

2. -

3. -

4. -

5. -

6. -

- :
1. -
 2. -

INSTRUCTIONS:

1. .
2. , ,
3. , ,
4. , , , ,
5. .
6. , ,
7. , ,
8. , , , , , , , ,
9. 4 + 5 . косую бейку
10. , ,

. Because of the pleats, the neckline of the dress may turn out too thick depending on the fabric used. In this case we recommend to use bias tape for neckline finishing, instead of the neckline facings provided in the pattern. Cut away the seam allowances along neckline, cut or take ready bias tape, its width should equal 4 cm and the length should equal the length of the neckline plus 5 cm. Fold bias tape in half wrong sides together and press. Straighten the tape, fold the edges towards the center and press. Sew on bias tape along the neckline from the right side, turn it onto the wrong side and stitch-in-the-ditch.

TECHNICAL DRAWING:

