

Dress With Darts Into Neckline - Выкройка #4792

Recommendations on fabric: natural/mixed fabric suitable for dresses.

You will also need: fusible interfacing; dress zipper.

Seam allowances: all seams 1 cm; seam allowance for hem of dress — 1.2 cm.

О припусках на швы::

- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:

Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.



РАСКРОЙ:

Обратите внимание при раскрое:

Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроются со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.

При стачивании деталей, обращайтесь внимание на надсечки, они должны совпадать.

Main fabric:

1. Upper back - cut 2
2. Lower back - cut 2
3. Upper front - cut 1
4. Lower front - cut 1 on fold
5. Back neck facing — cut 2
6. Front neck facing — cut 1
7. Upper sleeve - cut 2

8. Lower sleeve - cut 2
9. Cuff - cut 2

Fusible interfacing:

1. Back neck facing — cut 2
2. Front neck facing — cut 1
3. Cuff - cut 2

Инструкции:

1. Apply fusible interfacing.
2. Sew darts on upper backs and upper fronts, press the inner part towards center.
3. Sew upper back to lower back, press towards top and serge. Sew upper front to lower front, press towards top and serge.
4. Serge the center back edges separately. Sew the center back seam from zipper mark to hem, press the seam apart. Sew in zipper.
5. Sew side and shoulder seams, press towards the back and serge.
6. Sew shoulder seam on front neckline facing and back neckline facing, clip into curves and press apart. Serge the outer edge.
7. Pin facing to garment right sides together and sew the neckline. Clip seam allowances, turn facing onto wrong side, straighten, press. Slipstitch facing to shoulder seams and to zipper tape.
8. Sew, press and serge elbow and front sleeve edges. Sew sleeves into armholes matching notches, adjusting ease on sleeve cap, serge.
(8. Sew, press and serge the sleeve seam. Sew sleeves into armholes matching notches, adjusting ease on sleeve cap, serge. Hem of sleeve serge, press onto wrong side and topstitch.)
9. Fold cuff in half lengthwise, right sides together and sew ends from fold to notch. Trim away corners, snip into seam allowance near the mark. Fold cuff into ring and sew from mark to edge. Turn cuff right side out, straighten, press. Pin cuff to wrong side of sleeve, align cuff seam with mark and sew to sleeve hem, serge and press. Fold cuff to right side.
10. Serge lower edge of garment, press onto wrong side and topstitch.

Технический рисунок:

