

Coat With Wrap - Sewing Pattern #4801

Recommendations on fabric: natural/mixed fabric suitable for coats.

You will also need: lining; shoulder pads; sleeve heads; fusible interfacing; 1 button.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 3.0 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back – cut 2
2. Front – cut 2
3. Sleeve – cut 2
4. Collar – cut 2
5. Buttonstand (center front facing) – cut 2
6. Back neck facing – cut 1

Lining:

1. Back – cut 2
2. Front – cut 2
3. Sleeve – cut 2

Fusible interfacing:

1. Front — cut 2
2. Buttonstand (center front facing) — cut 2
3. Collar – cut 1
4. Back neck facing - cut 1

Also apply fusible interfacing to armhole areas on back and front, hem of garment and hem of sleeve.

Attention! Lining is cut using pattern blocks for self fabric, except for the width of center front facing and back neckline facing.

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew center back seam, press seam apart.
3. Sew darts on front, press bulk towards top.
4. Sew shoulder and side seams, press seam apart.
5. Sew shoulder seams of buttonstands and facings, press seam apart.
6. Cut a belt loop, its width should equal 7 cm its length should equal 8 cm. Fold in half lengthwise along longer side and sew. Press seam apart. Turn the loop right side out, and straighten seam allowances. Fold in half and sew to front neckline.
7. Pin collars together, right sides together, and sew corner, upper edge and the tail up to round mark. Trim away corners, collar turn right side out and press. Start and stop stitching exactly at the marked line of the neckline seam of collar. Clip into seam allowances near mark. Sew upper collar into self neckline.
8. Serge seam allowance along hem and press it onto wrong side. Place buttonstand onto front right sides together. Pin together buttonstand (center front facing) and top of garment and sew along the buttonstand edge and along neckline. Sew lower edge of buttonstand to front exactly according to the marked line of hem, stepping back from inner size of buttonstand at 1.5 cm. Turn buttonstands (center front edges) right side out onto right side, straighten seams.
9. Sew and press apart sleeve seam. Sew a line with short stitches along upper edge of sleeve cap. Gather

fullness and press gathered ease. Sew sleeves into armholes matching notches and adjusting ease. Sew shoulder pads and sleeve heads to garment.

10. Sew darts and seams on lining, sew in sleeves, leaving an opening for turning in a sleeve. Sew lining to inner edges of buttonstands and to back neckline facing. Sew lining to hem of coat and hem of sleeve. Turn right side out through the opening. Sew the opening closed.

11. Make button loop and sew on button.

TECHNICAL DRAWING:

