Dress With Fly Piece - Sewing Pattern #4810

Recommendations on fabric: natural/mixed fabric suitable for dresses in contrasting or similar color; fabric for decoration.



You will also need: dress zipper, fusible interfacing, 2 grommets.

Seam allowances: all seams 1 cm; seam allowance for hem of dress – 2.0 cm, seam allowance along vent – 6 cm.

Note on seam allowances:
- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:
Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

CUTTING:

Note on cutting:
On the pattern pieces, “beam” means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.
When sewing the garment, pay attention to notches, they must match up.

Main fabric 1:
1. Center back - cut 2
2. Side back - cut 2
3. Fly center front – cut 2
4. Fly side front - cut 2
5. Fly lower front - cut 2
6. Upper sleeve - cut 2
7. Lower sleeve - cut 2

8. Center front facing – cut 2
9. Back neck facing – cut 2
10. Front neck facing – cut 1

Main fabric 2:
1. Center front – cut 1 on fold
2. Side front - cut 2
3. Belt – cut 1

Decorative fabric:
1. Collar – cut 4
2. Cuff – cut 2

Fusible interfacing:
1. Center front facing – cut 2
2. Back neck facing – cut 2
3. Front neck facing – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing to center front facings (button stands) and facings.

2. Sew side backs to center back, press towards center and serge.

3. Trim away 5 cm on left center back along vertical edge of the vent. Apply interfacing to the vent on both sides of center back on the wrong side. Mark center seam line (vent fold-line) from the right side. Press left part along vent fold, on the right side press onto wrong side only the seam allowance of right side of vent (6 cm). Align pieces along center seam and baste together along upper edge of vent. Serge seam allowances of vent. Sew center back seam from mark to vent corner. Clip into seam allowance of vent in corner on right part. Press apart center seam, press seam allowances of the vent and sew them together by machine. Sew in zipper.

4. Sew side fronts to front, press towards center and serge. Sew side fly front to center fly front, press towards center and serge. Sew lower fly front to upper fly front, press towards top and serge.

5. Pin together collars right sides together and sew the outer edge. Clip into curves, trim away corners. Turn collar right side out.

6. Serge the outer edge of neckline facing. Pin facing to neckline of inner front right sides together, inserting collar and sew the neckline. Clip into curves, fold facing onto wrong side, straighten, press.

7. Serge outer edge of center front facing. Pin center front facing to fly front right sides together and sew center front edge. Clip into curves, fold the central front facing towards wrong side, straighten, press.

8. Serge lower edges of fronts, press onto wrong side and finish with hidden stitches. Pin fly front onto inner front, baste together along edges and treat as one piece in the future.

9. Serge lower edge of back neckline facing. Pin back neckline facing onto self garment right sides together and sew neckline exactly up to the marked line of shoulder seam. Clip seam allowances.

10. Sew shoulder seams, placing shoulder edge of front between facing and the shoulder edge of back. Press seams towards back, serge. Turn pieces right side out, press. Baste seam allowances of center seam to zipper tape.

11. Serge the lower edge of the sleeve. Pin together back and front, right sides together. Adjust the side seams starting at the armhole-the back side edge is longer than front side edge by the width of seam allowance along hem. Fold away seam allowance for back hem and sew side seams, placing side edge of front between side edge of back and seam allowance on hem. Press seams towards back, serge. Turn pieces right side out, press.

12. Sew, press and serge elbow and front sleeve edges. Sew sleeves into armholes matching notches, adjusting ease on sleeve cap, press seam, serge.

13. Fold cuff in half lengthwise, right sides together and sew short sides. Turn cuff right side out, straighten, press. Pin short sides of cuff one onto another, matching notches. Sew cuff to lower edge of sleeve, press seam allowances towards sleeve, serge. Topstitch seam allowances onto garment with seam 0.5 cm.

14. Press seam allowance for back hem onto wrong side and slip stitch.

15. Fold belt in half lengthwise right sides together and sew around all edges, leaving an opening for turning. Turn belt right side out, straighten and press. Sew the opening closed.

16. Install grommets on fly fronts. Thread in belt into them.

TECHNICAL DRAWING:

