Jacket With Asymmetrical Closure - Sewing Pattern #4829

Recommendations on fabric: natural/mixed fabric suitable for coats in similar or contrasting colours.

You will also need: lining; fusible interfacing; 2 zippers; 1 separating zipper; shoulder pads.



Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve – 3.5 cm.

Note on seam allowances:
- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:
Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

CUTTING:

Note on cutting:
On the pattern pieces, “beam” means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.
When sewing the garment, pay attention to notches, they must match up.

Main fabric:
1. Center back – cut 2
2. Side back – cut 2
3. Center front – cut 2
4. Side lower front – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2
7. Center front facing – cut 2

8. Back neck facing – cut 1

Main fabric 1:
1. Back yoke – cut 1
2. Side upper front – cut 2

Fusible interfacing:
1. Center front – cut 2
2. Center front facing – cut 2
3. Back neck facing – cut 1

Lining:
1. Center back – cut 2
2. Side back – cut 2
3. Back yoke – cut 1
4. Front lining – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2
7. Small pocket bag – cut 2
8. Large pocket bag – cut 2

Attention: Back yoke from lining is cut using the pattern block for main fabric, except for the width of back neckline facing.

INSTRUCTIONS:

1. Apply fusible interfacing.

2. Sew side backs to center back, press towards center. Sew center back seam, press the seam apart. Sew yoke to back, press seam allowances towards yoke.

3. Sew upper side front to lower side front, press towards top.

4. Mark the position of pockets with parallel lines. Cut the slit for pocket opening. Slash diagonally at 1-1.5 cm from the end of the marked slit. Turn the seam allowances onto the wrong side through the resulting opening, straighten edges. Pin zipper under the opening so that you can see the teeth and sew. Sew right side of lining to the wrong side of zipper tape. Sew edges of lining.

5. Sew left side front to left center front, inserting the left side of zipper tape, press the seam apart. Sew right side front to center front, press the seam apart.

6. Sew side and shoulder seams, press the seam apart. Sew center collar seam, press the seam apart. Sew one-piece collar into neckline, clipping into seam allowance near corner. Clip seam allowances and press apart.

7. Sew side seams of center front facings and back neckline facings, press the seam apart. Sew center collar seam, press the seam apart. Sew one-piece collar into neckline, clipping into seam allowance near corner. Clip seam allowances and press apart.

8. Sew right side of zipper to the edge of right front, teeth are directed away from the edge. Pin center front facings to Shell right sides together and sew center front edges collar edge and lower corner of front. Clip into curves, trim away corners, turn pieces right side out. Sew a decorative stitch along front edge and collar at 0.5 – 0.7 cm.

9. Sew elbow seam on sleeve, press the seam apart. Press the hem of sleeve. Sew front seam on sleeve, press the seam apart. Sew sleeves into armholes matching notches. Sew shoulder pads.

10. Sew seams on lining and sew in sleeves, leaving a technical opening in the right front sleeve seam. Press seam allowances of lining.

11. Sew lining to the central front facings and to facing, press seam. Turn garment right side out, straighten seams.

12. Mark the lower seam allowance, fold it under and press. Sew lining to lower edge. Turn garment right side out through the opening in sleeve. Sew lining to lower edge of sleeve. Sew the opening closed.

TECHNICAL DRAWING:

