

Dress With Batwing Sleeves - Выкройка #4841

Recommendations on fabric: natural/mixed fabric suitable for dresses.

You will also need: fusible interfacing, dress zipper, 6 buttons.

Seam allowances: all seams 1 cm; seam allowance for hem - 3.0 cm.

О припусках на швы::

- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.

- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:

Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.



РАСКРОЙ:

Обратите внимание при раскрое:

Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроются со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.

При стачивании деталей, обращайтесь внимание на надсечки, они должны совпадать.

Main fabric:

1. Back - cut 2
2. Front - cut 1 on fold
3. Cuff - cut 2
4. Back neck facing - cut 2
5. Front neck facing - cut 1

Fusible interfacing:

1. Cuff - cut 2
2. Back neck facing - cut 2
3. Front neck facing - cut 1

Инструкции:

1. Apply fusible interfacing to neckline facings and cuffs.
2. Serge center back edges separately. Sew center back seam from notch for zipper to bottom, press the seam apart. Sew in zipper.
3. Serge shoulder edges separately on each piece. Sew shoulder seams up to notch, press the seam apart. Topstitch seam allowances along slit at 0.1 cm from the edge.
4. Sew side seams sewing the sleeve edges at the same time, press towards the back and serge.
5. Sew the shoulder seams of the neckline facings, serge the outer edge. Make a slit along the marked line on front and on front facing. Pin facing to dress right sides together, adjusting neckline edges, and sew (sew neckline at 0.1-0.2 cm from the edge). Clip into curves, turn the facing onto the wrong side and press. Slip stitch facing to shoulder seam and zipper tape.
6. Fold cuff in half lengthwise, right sides together and sew edges and corner of the cuff. Clip into seam allowance near notch. Turn right side out and press. Sew outer side of cuff to sleeve. Fold under the seam allowance of the inner side inside and stitch-in-the-ditch along seam of outer side.
7. Serge bottom edge of dress, press onto wrong side and finish with hidden stitches.
8. Make buttonholes on cuffs and sew on buttons.

Tip: use a decorative closure to keep the edges of the front slit in place.

Технический рисунок:

