Blouson With Lace Inset - Sewing Pattern #4845



Recommendations on fabric: natural/mixed knit fabric of small stretchiness. Guipure in contrasting or similar color.

You will also need: knit fusible interfacing.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve – 2 cm.

Note on seam allowances:
- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:
Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

CUTTING:

Note on cutting:
On the pattern pieces, “beam” means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.
When sewing the garment, pay attention to notches, they must match up.

Main fabric 1:
1. Lower back – cut 1 on fold
2. Lower front – cut 1 on fold
3. Sleeve – cut 2
4. Back neck facing – cut 2
5. Front neck facing – cut 2

Main fabric 2:

1. Upper back – cut 1 on fold
2. Upper front – cut 1 on fold

Fusible interfacing:
1. Back neck facing – cut 1
2. Front neck facing – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing to facings.

2. Sew shoulder seam on upper front and upper back. Serge seams and press towards back.

3. Sew sleeve to front and to back. Serge and press onto sleeve.

4. Sew upper part to lower part. Clip into corner of seam allowance, serge and press onto sleeve.

5. Sew side seams sewing the sleeve edges at the same time, press towards the back and serge.

6. Sew shoulder seams of facings, press the seam apart. Serge the outer edge. Pin together facings right sides together and sew the neckline. Clip into curves, turn facings onto right side and press. Sew outer facings into neckline, clip seam allowances and press towards facing. Fold seam allowance of inner facing under and stitch in the ditch

7. Serge lower edge of garment and lower edge of sleeve, press onto wrong side and topstitch.

TECHNICAL DRAWING:

