Dress With Pleats - Выкройка #4934

Recommendations on fabric: natural/mixed fabrics with elastane suitable for dresses.

You will also need: dress zipper, fusible interfacing.

Seam allowances: all seams 1 cm; seam allowance for hem of dress – 2 cm; seam allowance for hem of sleeve — 1.5 cm.



О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

О работе с эластичными тканями:
Детали выкройки из трикотажа стачиваются специальным эластичным швом или швом зигзаг. Припуск на подгибку низа может быть настрочен двойной иглой для сохранения эластичности. Детали также можно стачать при помощи оверлока. При стачивании оверлоком, пожалуйста, обрежьте припуски на швы до ширины 0.6 - 0.8 см.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Upper back - cut 2

2. Back belt — cut 2
3. Lower back - cut 2
4. Upper front – cut 1 on fold
5. Front belt — cut 1
6. Lower front — cut 1 on fold
7. Sleeve - cut 2
8. Back neck facing - cut 2
9. Front neck facing - cut 1
10. Pocket bag - cut 4

Инструкции:

1. Make and baste pleats on lower fronts and on lower backs.

2. Sew darts on back, press bulk towards center. Sew back belt to upper back, press seam allowances towards belt and serge. Sew lower back to belt, press seam allowances towards belt and serge.

3. Serge center back edges separately. Sew center back seam from notch for zipper to bottom, press the seam apart. Sew in zipper.

4. Make and baste pleats on the neckline of upper front (fold bulks from center). Sew front belt to upper front, press seam allowances towards belt and serge. Sew lower front to belt, press seam allowances towards belt and serge.

5. Sew pocket bags to lower backs and lower front, serge and press towards pocket bag. Sew side seams, sewing pocket bags at the same time. Serge the seam allowances and press onto front.

6. Sew shoulder seams, press towards the back and serge.

7. Sew the shoulder seams of the neckline facings, press the seam apart. Serge the outer edge. Pin facing to garment right sides together and sew the neckline. Fold the facing onto wrong side, straighten, press. Slip stitch facing to self garment along shoulder seams and center back seam.

8. Serge lower edge of sleeve, fold inside the seam allowance and topstitch. Sew sleeves into armholes, serge and press.

9. Cut (or take ready) bias tape, its width should equal 4 cm and length should equal the length of lower armhole + 6 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape onto armhole edge from the right side, leaving loose ends, and sew. Fold bias tape onto wrong side, clip into seam allowances and topstitch onto main piece along the fold. Press seam.

10. Serge lower edge of dress, press onto wrong side and topstitch.

Технический рисунок:

