

4935 - Sewing Pattern #4935

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing; 4 buttons.

Seam allowances: Seam allowance for hem of garment and hem of sleeve – 1.5 cm; other seams – 1 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 1 on fold
2. Front - cut 1 on fold
3. Front inset – cut 2
4. Back yoke – cut 1 on fold
5. Placket — cut 4
6. Sleeve – cut 2
7. Sleeve decorative tab – cut 2

8. Neckline facing – cut 2

Fusible interfacing:

1. Neckline facing – cut 1
2. Placket – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Make pleats on back, fold bulk towards center. Sew back yoke to yoke. Press seam towards yoke and serge.
3. Sew a gathering stitch along upper edge of front and gather fullness. Sew inset to front, press towards front and serge.
4. Sew side and shoulder seams, press towards the back and serge.
5. Pin plackets together by two and sew the outer edge. Turn pieces right side out and press. Make buttonholes on right placket. Sew plackets to right side of front along longer edge, stop at 1 cm from the bottom. Snip into seam allowance on front, leaving 1 mm to the stitch line. Thread the ends of plackets inside and sew, fastening the lower edge. Serge seam allowances.
6. Pin neckline facings together, right sides together, and sew outer edges. Start and stop sewing exactly at the marked line of seam. Clip into curves. Turn the ready facing right side out and press. Sew upper facing into neckline, press seam allowances towards placket. Turn the raw edge of lower facing under and stitch in the ditch along the seam of upper facing.
7. Fold decorative tabs in half lengthwise right sides together and sew along longer and one shorter edge. Turn right side out, slashing seam allowances in corners, straighten and press. Serge raw shorter edge. Topstitch decorative tabs according to the markings onto the wrong side of sleeves.
8. Sew sleeve seams, press towards back and serge. Sew sleeves into armholes, serge and press.
9. Serge hem of garment and hem of sleeve, turn inside and topstitch.
10. Sew on buttons onto left front. Make buttonholes on decorative tabs, sew on buttons onto sleeves.

TECHNICAL DRAWING:

