Blouse With Ties - Sewing Pattern #4939



Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing.

Seam allowances: Seam allowance for hem of garment and hem of sleeve – 2 cm; other seams – 1 cm.

Note on seam allowances:
- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:
Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

CUTTING:

Note on cutting:
On the pattern pieces, “beam” means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.
When sewing the garment, pay attention to notches, they must match up.

Main fabric:
1. Back - cut 1 on fold
2. Front - cut 1 on fold
3. Front neck facing – cut 1
4. Back neck facing – cut 1
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2
7. Collar – cut 1

Fusible interfacing:
1. Front neck facing – cut 1
2. Back neck facing – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.

2. Sew darts on front. Press bulk towards top. Sew darts on back. Press bulk towards center.

3. Cut a strap main fabric , its width should equal 4 cm, its length should equal 50 cm. Pin together in half lengthwise and press. Turn long edges under and press. Sew a stitch at 0.2 cm from the edge. Cut in two.

4. Sew side and shoulder seams, press towards the back and serge.

5. Sew the shoulder seams of the neckline facings. Press the seam apart. Serge the outer edge.

6. Fold collar in half lengthwise right sides together and sew corners. Trim seam allowances, turn right side out and press. Sew collar into neckline, making pleats as desired.

7. Pin facing onto blouse, right side down, and sew neckline and neckline edge, inserting the ties. Trim seam allowances, clip into curves, fold facing onto wrong side. Slip stitch facing to shoulder seams.

8. Sew upper sleeve to lower sleeve. Serge and press towards top. Sew sleeve seams, press towards back and serge. Sew sleeves into armholes, serge and press.

9. Serge hem of garment and hem of sleeve, turn inside and topstitch.

TECHNICAL DRAWING:

