

Coat From Knit Fabric - Sewing Pattern #4955

Recommendations on fabric: thick natural/mixed knit fabric of small stretchiness.

You will also need: lining; fusible interfacing; separating zipper; 2 decorative zippers; 4 buttons; 10 flat buttons for hood.

Seam allowances: all seams 1 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

Note on working with stretchy fabric:

Knitted fabric pieces are sewn together with special elastic or narrow zig-zag stitch. Seam allowance on hems can be stitched with twin needles to save stretchiness. Pieces can also be sewn together with a serger. When serging, cut seam allowances to 0.6 – 0.8 cm.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back – cut 1 on fold
2. Side – cut 2

3. Front – cut 2
4. Back neck facing – cut 1
5. Center front facing – cut 2
6. Hem facing – cut 1 on fold
7. Stand collar – cut 2
8. Hood – cut 2
9. Hood facing – cut 2
10. Sleeve – cut 2
11. Cuff – cut 2
12. Pocket – cut 2

Lining:

1. Back lining – cut 1 on fold
2. Side lining – cut 2
3. Front lining – cut 2
4. Hood – cut 2
5. Sleeve – cut 2
6. Pocket – cut 2

Fusible interfacing:

1. Center front facing – cut 2
2. Back neck facing – cut 1
3. Hem facing – cut 2
4. Stand collar – cut 1
5. Hood facing – cut 1
6. Cuff – cut 2
7. Pocket – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew front darts, press bulk towards top.
3. Mark the position of pocket on front. Mark the position of zipper on pocket. Cut the slit for pocket opening. Slash diagonally at 1-1.5 cm from the end of the marked slit. Turn the seam allowances onto the wrong side through the resulting opening, straighten edges. Pin zipper under the opening so that you can see the teeth. Sew in zipper. Pin pocket to lining right sides together and sew, leaving an opening for turning. Clip seam allowances, trim away corners. Turn right side out pocket onto right side, straighten, press. Topstitch pocket onto front along the side edges and horizontal line, forming a flap from the lower part of pocket.
4. Sew side backs to center back, press the seam apart. Sew side fronts to front, press the seam apart. Sew shoulder seams, press the seam apart.

5. Sew outer stand collar into neckline, clip seam allowances and press apart.
6. Sew shoulder edges of center front facings and back neckline facing, press the seam apart. Sew inner stand collar into neckline, clip seam allowances and press apart. Sew hem facing to center front facings, press the seam apart.
7. Place center front facing onto front right sides together and sew around along the center front edge, inserting zipper, lower edge and edge of stand collar. Clip into curves, trim away corners. Turn center front facings and facings onto wrong side, straighten, press.
8. Sew sleeve seam, press the seam apart. Sew sleeves into armholes, press seam.
9. Sew cuff into a ring, press the seam apart. Fold cuff in half lengthwise and press right side out. Sew outer side of cuff to lower edge of sleeve, press towards cuff.
10. Sew seams on lining and sew in sleeves, leaving an opening in left side seam.
11. Sew lining to central front facings and to facings. Sew lining to inner side of cuff. Turn garment right side out through the opening. Baste together seam allowances of stand collars and seam allowances of cuffs. Sew the opening closed.
12. Проложить отделочно закрепляющую строчку along lower edge. Sew at pocket buttons.
13. Sew hood seam, press the seam apart. Sew facing to hood, press seam allowances towards placket. Sew hood lining in the same way. Pin hood to lining right sides together and sew around all edges, leaving an opening for turning. Clip into curves, trim away corners. Turn the hood right side out, straighten, press. Sew the opening closed.
14. Make buttonholes on hood neckline. Sew buttons onto the seam of stand collar.

TECHNICAL DRAWING:

