

Waterproof Jacket - Sewing Pattern #4961

Recommendations on fabric: natural/mixed waterproof fabrics suitable for outdoor jackets.

You will also need: lining; fusible interfacing; separating zipper; decorative cord; 2 cord stops, 2 eyelets.

Seam allowances: all seams 1 cm. Seam allowance along lower edge of garment and lower edge of sleeve – 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Lower back — cut 1 on fold
2. Lower front - cut 2
3. Back neck facing - cut 1
4. Center front facing - cut 2
5. Casing - cut 1

Main fabric 1:

1. Back yoke - cut 1 on fold
2. Front yoke - cut 2

Main fabric 2:

1. Front inset - cut 2
2. Collar - cut 1

Lining:

1. Back lining - cut 2
2. Front lining - cut 2

Fusible interfacing:

1. Center front facing - cut 2
2. Back neck facing - cut 1
3. Collar - cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew back yoke to yoke. Press towards top.
3. Sew front inset to front yoke. Press seam apart. Sew upper front to lower front. Press seam allowances towards yoke.
4. Sew shoulder seams. Press seam apart. Sew in sleeves. Press towards yokes. Sew side seams and sleeve seams. Press seams towards back.
5. Install grommets on front. Pin casing onto front and onto back from the wrong side and sew along the marked lines.
6. Sew outer collar into neckline. Clip into seam allowances and press apart.
7. Sew shoulder seams of buttonstands and facings. Press seam apart. Sew inner stand collar into neckline. Clip into seam allowances and press apart.
8. Place center front facing onto front right sides together and sew along the center front edge, inserting zipper, sewing the collar at the same time.
9. Sew seams on lining, leaving an opening in left side seam.
10. Baste together seam allowances of neckline and collar. Sew lining to the central front facings and to facing.

Sew lower edge of lining to hem of garment. Sew lining to hem of sleeve. Turn right side out through the opening. Sew the opening closed. Thread in the cord, install cord stops and eyelets. Stitch decorative/fixing stitches along hem of jacket and hem of sleeve.

TECHNICAL DRAWING:

