Waterproof Jacket - Sewing Pattern #4961

Recommendations on fabric: natural/mixed waterproof fabrics suitable for outdoor jackets.

You will also need: lining; fusible interfacing; separating zipper; decorative cord; 2 cord stops, 2 eyelets.

Seam allowances: all seams 1 cm. Seam allowance along lower edge of garment and lower edge of sleeve – 3 cm.



Note on seam allowances:
- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:
Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

CUTTING:

Note on cutting:
On the pattern pieces, “beam” means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.
When sewing the garment, pay attention to notches, they must match up.

Hauptstoff:
1. Unterer Rückenteil — 1 Stück am Falz
2. Unteres Vorderteil – 2 Stück
3. Hinteres Halsausschnittbesatz – 1 Stück
4. Mittelvorderbesatz – 2 Stück
5. Tunnel für Kordelzug – 1 Stück

Hauptstoff 1:
1. Rückenpasse – 1 Stück am Falz
2. Vorderpasse – 2 Stück

Hauptstoff 2:
1. Vordereinsatz – 2 Stück
2. Kragen – 1 Stück

Futterstoff:
1. Rückenfutter – 2 Stück
2. Frontfutter – 2 Stück

Klebevlies:
1. Mittelvorderbesatz – 2 Stück
2. Hinteres Halsausschnittbesatz – 1 Stück
3. Kragen - 1 Stück

INSTRUCTIONS:

1. Klebevlies auftragen.

2. Rückenpasse an Ruckenteil nähen. Bügeln nach oben.

3. л4640. Die Naht auseinander bügeln. Oberes Vorderteil an unteres Vorderteil nähen. Nahtzugaben auf passe bügeln.

4. Nähen Schulternähte. Die Naht auseinander bügeln. Ärmel einnähen. Bügeln Sie zu passe. Seitennähte und Ärmelnähte nähen. Nähte zum Rückenteil bügeln.

5. Ösen einbauen am Vorderteil. Stecken Sie den Tunnel von der Rückseite auf das Vorderteil und das Rückenteil und nähen Sie entlang der markierten Linien.

6. Den äußeren Kragen in den Halsausschnitt nähen. In Nahtzugaben einclipsen und auseinander bügeln.

7. Schulternähte der vorderen Mittelbesätze nähen und Besätze. Die Naht auseinander bügeln. Den inneren Stehkragen in den Halsausschnitt einnähen. In Nahtzugaben einclipsen und auseinander bügeln.

8. Vorderen Mittelbesatz rechts auf rechts auf das Vorderteil legen und nähen entlang der mittleren Vorderkante, Reißverschluss einführen, nähen Sie dabei gleichzeitig den Kragen.

9. Nähte am Futter nähen, eine Öffnung hinterlassen in der linken Seitennaht.

10. л4644. Futter an die vorderen Mittelbesätze und an den Besatz nähen. Die Unterkante des Futters an den

Saum des Kleidungsstücks nähen. Futter an den Ärmelsaum nähen. Auf rechts wenden durch die Öffnung. Die Öffnung zunähen. Fädeln Sie die Kordel ein, л4645 und л3971. л4646.

TECHNICAL DRAWING:

