

Jacket With Hood - Sewing Pattern #4966

Recommendations on fabric: natural/mixed fabrics suitable for raincoats.

You will also need: lining; fusible interfacing; separating zipper; decorative cord; 2 grommets; 2 cord ends; 4 buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and for upper edge of pocket - 3 cm

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 1 on fold
2. Front - cut 2
3. Sleeve - cut 2
4. Back neck facing - cut 1
5. Center front facing - cut 2
6. Placket - cut 2

7. Hood – cut 2
8. Center hood – cut 1
9. Hood facing – cut 2
10. Pocket – cut 2
11. Flap – cut 4
12. Cuff – cut 2
13. Decorative Tab – cut 2
14. Casing for drawstring – cut 1 on fold

Fusible interfacing:

1. Placket – cut 2
2. Center front facing – cut 2
3. Back neck facing – cut 1
4. Flap – cut 2
5. Hood facing – cut 1
6. Cuff – cut 2

Lining:

1. Back – cut 2
2. Front – cut 2
3. Sleeve – cut 2
4. Hood – cut 2
5. Center hood – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Make and baste a box pleat on pocket. Fold under the upper seam allowance of pocket at 1 cm, then at 2 cm and topstitch. Fold under side and lower edges of pocket and press. Pin pockets onto fronts according to markings and topstitch. Pin together flaps right sides together and sew outer edges. Clip into curves, turn flaps right side out, straighten, press. Sew a decorative stitch on flap at 0.5 cm from the edge. Serge upper edge. Sew flaps to fronts (the corner is directed towards neckline), fold down and topstitch.
3. Sew shoulder seams, press seam apart.
4. Sew sleeves to garment, press seam allowances towards sleeve. Sew side seams, sewing the sleeve edges at the same time, press seams towards back.
5. Install grommets on Front according to markings. Fold under and press all seam allowances of casing onto the wrong side. Pin casing onto garment, wrong sides together and topstitch.
6. Sew side hoods to center hood, press seam allowances towards center part. Sew facing to hood, press

towards facing.

7. Sew hood into neckline, press seam apart.

8. Fold left placket in half lengthwise right sides together and sew shorter edges. Turn right side out, straighten, press. Pin left part of zipper onto the center front edge and the edge of the hood (teeth are directed away from the edge), pin left placket onto it, and sew. Pin right part of zipper onto the center front edge and the edge of the hood (teeth are directed away from the edge), and sew.

9. Sew shoulder edges of center front facings and back neckline facing, press seam apart. Sew hood from lining, press seams onto center part. Sew facing to lining капюшона, press towards facing. Sew hood into neckline of center front facings, press seam apart.

10. Pin center front facings and hood to Shell right sides together and sew around the outer edge of center front facings and hood. Clip into curves, trim away corners. Turn right side out center front facings onto wrong side, straighten, press. Baste together seam allowances of the hood seam.

11. Sew cuff into a ring, press seam apart. Fold cuff in half lengthwise and press right side out. Sew cuff to lower edge of sleeve.

12. Fold decorative tab in half, right sides together, and sew longer edge and corner. Trim seam allowances, turn tab right side out, press and sew a decorative stitch at 0.1 cm from the edge. Sew decorative tab to inner cuff according to markings.

13. Sew lining, leaving an opening in left side seam. Sew lining to facing, center front facings, to hem of jacket. Turn the garment right side out through the opening. Sew lining to hem of sleeve through the opening, press seam. Sew the opening closed. Sew a decorative/fixing stitch along hem of jacket at 2 cm from the edge.

14. Fold right front placket in half lengthwise, right sides together, and sew corners. Turn right side out and press. Sew decorative stitches along outer fold, along upper and lower edge. Serge inner edge. Pin placket onto front (the edge of placket is directed away from center front edge) and topstitch along the marked line. Fold placket, covering the closure and topstitch along the seam.

15. Make buttonholes on right placket and on decorative tabs. Sew on buttons correspondingly. Thread cord into casing, attach cord ends.

TECHNICAL DRAWING:

