

Jacket With Peplum - Sewing Pattern #4978

Recommendations on fabric: natural/mixed knit fabric of small stretchiness.

You will also need: fusible interfacing; separating zipper.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment - 1.5 cm. Seam allowance for hem of sleeve - 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

Note on working with stretchy fabric:

Knitted fabric pieces are sewn together with special elastic or narrow zig-zag stitch. Seam allowance on hems can be stitched with twin needles to save stretchiness. Pieces can also be sewn together with a serger. When serging, cut seam allowances to 0.6 – 0.8 cm.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 2
2. Back peplum - cut 1 on fold

3. Center front – cut 2
4. Side front – cut 2
5. Front peplum – cut 2
6. Upper sleeve – cut 2
7. Lower sleeve – cut 2
8. Back neck facing – cut 1
9. Center front facing – cut 2

Fusible interfacing:

1. Back neck facing – cut 1
2. Center front facing – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing. Also apply fusible interfacing to seam allowances along hem of garment and hem of sleeve.
2. Sew center back seam, press towards left and serge. Sew peplum to back, press towards top and serge.
3. Sew side fronts to front, press seams towards center and serge. Sew peplum to front, press towards top and serge.
4. Sew side and shoulder seams, press towards the back and serge.
5. Sew side seams of back neckline facing and central front facings, press seam apart. Serge the outer edge. Pin center front facings and facing onto Shell, right sides together, insert zipper between the pieces and sew center front edge, neckline and lower corner. Trim away corners, clip into curves. Fold the center front facings onto right side, straighten seams, press.
6. Sew elbow and front sleeve seam, serge and press. Sew sleeves into armholes matching notches, serge and press.
7. Serge lower edge of garment and lower edge of sleeve, press onto wrong side and topstitch.

TECHNICAL DRAWING:

