

Sewing Pattern — Trousers 5141

Recommendations on fabric: silk of 150 cm width
You will also need: 1 zipper-22 cm length; 1 button
If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: all seams 1 cm, hem 2 cm

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches. They must match up with corresponding pieces



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

Fabric:

1. Front – cut 2
2. Back – cut 2
3. Waistband – cut 1
4. Belt loop – cut 4
5. Button catch – cut 1

Fusible interfacing: waistband

INSTRUCTIONS:

1. Apply the interfacing to wrong side of waistband.
2. Sew darts, press toward center.
3. Pin fronts right sides together, sew center front seam from notch mark to 2 cm below step seam.

4. ZIPPER: press the zipper closure one-piece facing onto wrong side. Sew the zipper under the allowance edge (left edge) along the edge. Sew free zipper tape to right edge, to one-piece facing. Fold the button catch along the center, then sew it along upper and lower short edges. Topstitch the zipper closure one-piece facing on the button catch on the left part of the garment. Topstitch the slit right edge catching the facing.

(Suggested video How-to's if you are not familiar with sewing in pant zippers: Illustrations and explanation [Sew in Fly Zipper](#) and [Video: An Easy, Flat Fly-Front Zipper](#). Note: the zipper fly facing is not used in this method.)

5. Pin one front and one back right sides together. Sew side seams and inner leg seam. Press seam allowances apart.

6. Place one pant leg into the other pant leg, right sides together. Sew the center crotch. Press seam allowance apart, to crotch curve. Fold the waistband along the center, right side together, then sew front ends. Turn the waistband right side out. Sew outer waistband edge to outer upper edge of garment, right sides together, with the extended part for button on left. Turn seam allowance under on the inner side of waistband and topstitch in the ditch along the joining seam from the right side.

7. Serge bottom edge of pant leg. Fold onto wrong side, and topstitch.

8. Make a buttonhole on right end of waistband, sew the button on left.

TECHNICAL DRAWING:

