

Sewing Pattern — Dress 7111

Recommendations on fabric: thin silk or viscose.

You will also need: decorative cord.

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: all seams - 1 cm.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

- 1. Front part– 1 detail
- 2. Back part 2 details
- 3. Top frill 1 detail
- 4. Lower frill 1 detail

INSTRUCTIONS:

- 1. Sew center seam of back part, serge and press.
- 2. Sew side seams, serge and press towards back part.
- 3. Sew top frill into ring. Serge and press connecting seam. Sew the lower frill the same way.
- 4. Serge lower edge of top frill, turn inside and topstitch. Sew the lower frill the same way. Fold top and lower frills together right side to wrong side. Level and fix them along top edge of the frill. Stitch loosely at 0.5 cm off the edge. Gather upper edge of the detail according to the length of lower edge of the bodice, distributing the ruffles evenly throughout the length. Stitch the frill to the dress. Serge and press the seam.
- 5. Serge: neckline edge of front part, edge of back part neckline, edge of the front part armhole and back part armhole. Turn inside and topstitch: neckline edge of back part, edge of the armhole of front part and of back part.
- 6. Turn neckline edge of front part inside and put the stitch by 1 cm off the edge. Run the cord through the given slit, leaving the ties (from the cord, (please see the technical drawing). Try the dress on. Make frill volume at your pleasure. Fix the frill with barred ends on the cord.



TECHNICAL DRAWING:

