

Sewing Pattern — Dress 7070

Recommendations on fabric: cotton velvet/denim

You will also need: fusible interfacing; 2 buttons; zipper

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

SEAM ALLOWANCE: 1 cm for all seams.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must match up with corresponding pieces.



CUTTING:

Fabric:

1. Pocket – 1 piece
2. Right back part – 1 piece
3. Left back part – 1 piece
4. Right lower front part – 1 piece
5. Left lower front part – 1 piece
6. Front yoke – 2 pieces
7. Gusset – 2 pieces
8. Back facing – 1 piece
9. Front facing – 1 piece

Interfacing: front/back facings

INSTRUCTIONS:

1. Apply the fusing to wrong part of front/back facings.
2. Stitch the gusset to left lower front part. Neaten the seam and press it towards left lower part. Make decorative double stitch at 0.2 cm from the seam.

3. Stitch the gusset to left back part. Neaten the seam and press it towards left back part. Make decorative double stitch at 0.2 cm from the seam.
4. Stitch the yoke to right lower part, neaten the seam and press downwards. Stitch the yoke to left lower front part, neaten the seam and press it downwards. Make decorative double stitch at 0.2 cm from the seam.
5. Mark pocket place on front part. Stitch middle front seam making a notch into shaped corner. Neaten middle front seam. Press middle front seam and make decorative double stitch at 0.2 cm from the seam.
6. Press pocket upper edge into wrong side, fold it under and topstitch. Press pocket allowances into pocket wrong side according to pattern. Topstitch the pocket on front part according to marks.
7. Stitch middle back seam, making a notch into shaped corner. Neaten middle back seam. Press middle back seam and make decorative double stitch at 0.2 cm from the seam.
8. Neaten front/back side edges. Stitch side seams leaving closure slit into left seam. Press side seams apart pressing closure slit.
9. Stitch right side edge of front/back facings. Press facings right side seam. Neaten facings lower edges.
10. Stitch the zipper into side left seam of front part. Overstitch front armhole edge, strap upper edge, front neckline edge, back armhole edge, back strap rounded edge, back neckline edge with facings. Press facings into wrong side and make edging.
11. Stitch left side edge of facing to garment side seam. Make decorative double stitch at 0.2 cm from front neckline strap and back neckline.
12. Make buttonholes into back straps. Sew buttons on front straps.
13. Stitch fringe side edge and stitch fringe to garment hem. Neaten joining seam and press it towards garment.

TECHNICAL DRAWING:

