

# Sewing Pattern — Trousers 7044

Recommendations on fabric: semi-wool or cotton stretch fabric

You will also need: elastic gabardine; lining; fusing; 1 zipper; 1 button

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



#### **CUTTING**:

### Main fabric:

- 1. Button catch 1 piece
- 2. Pocket facing 2 pieces
- 3. Cut side 2 pieces
- 6. Waistband right part 2 pieces
- 7. Waistband left part 2 pieces
- 8. Waistband back part 2 pieces
- 9. Front part 2 pieces
- 10. Back part 2 pieces

## Lining:

- 1. Lower sacking 2 pieces
- 2. Upper sacking 2 pieces

Fusing: waistband details, button catch.

### **INSTRUCTIONS:**

Apply the fusing to wrong side of waistband and button catch.

Neaten facing edges of pockets and cut sides. Place facings on upper sackings and sides on lower



sackings, then topstitch. Topstitch pocket facings on pocket entrances right sides together. Cut joining seam allowance to 0.5 cm width. Turn facings into wrong side. Topstitch pocket entrances along the edges. Pin front parts on cut sides along marking, tack pocket entrances. Sew sackings.

Fold front parts right sides together. Sew front middle seam 2 cm before leg inside seam.

Press zipper closure one-piece facing into wrong side. Sew the zipper under closure allowance left edge. Sew zipper free braid on right edge to one-piece facing. Fold the button catch along the center, wrong side together, then neaten along short and long edges. Topstitch zipper closuew one-piece facing on the garment left edge button catch. Topstitch slit roght edge catching the facing.

Sew side and inside leg seams. Sew back edge and unsewn part of front edge in one seam. Press allowances apart to roundings.

Sew side seams in inner and outer yokes. Sew upper yoke and garment upper edge, right sides together. Press the joining seam towards the yoke. Put the inner yoke on the outer sewn yoke, right sides together, sew upper and front edges of inner and outer yokes. Turn yokes right side out, press, then topsting along the joining seam.

Press hem into wrong side, then topstitch.

Make a buttonhole into waistband right edge. Sew the button on left one.

### **TECHNICAL DRAWING:**

