

Sewing Pattern — Dress 5854

Recommendations on fabric: knitted fabric of low or medium stretchiness.

You will also need: elastic yarn

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Seam allowance: along the lower edge of the garment – 2.0 cm, along the lower edge of sleeve – 2 cm, all other seams - 0.7 cm

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Main fabric:

1. Upper back part – 1 detail
2. Lower back part – 1 detail
3. Back part inset – 1 detail
4. Upper front part – 2 details
5. Lower front part – 1 detail
6. Front part inset – 1 detail
7. Lower right front part – 1 detail

Advice:

Knitted fabric details are sewn together with special elastic or narrow zig-zag stitch. When serging cut seam allowances to 0.6 – 0.8 cm. Seam allowance on turnup is stitched with twin needles to save stretchiness. Details also can be sewn together via 3 or 4 – threaded serger.

INSTRUCTIONS:

1. Stitch loosely along side edges of back part and front part insets and gather ruffles to shown value (on inset pattern).
2. Stitch inset of back part to upper back part, press seam onto inset. Stitch lower back part to back part inset, press seam onto inset.
3. Make and stitch up pleats at 3 – 4 cm according to markers on upper front part and on lower right front part.

4. Slash seam allowance near shoulder seam on detail of one-piece buttonstand and serge seam allowance of shoulder edge and inner edge of buttonstand. Press buttonstand onto wrong side according to markers. Serge edge of one-piece buttonstand on lower right front part. Press buttonstand onto wrong side according to markers.
5. Put right upper front part onto left one and fix them along the lower edge. Stitch inset of front part to upper part, press seam onto inset.
6. Put right lower front part onto lower front part and fix them along top edge. Stitch lower front part to inset of front part, press seam onto inset.
7. Slash away seam allowance near shoulder seam on front part. Sew shoulder seams of back part and of front part. Press seams towards back part.
8. Sew center edge of collar. Fold collar in half, wrong sides together, align edges and sew into the neckline of back part.
9. Serge seam allowance of sleeve, press onto wrong side. Open seam allowance and put the stitch with elastic yarn along the fold between notches, placing elastic onto wrong side. Turn seam allowance onto wrong side and topstitch. Serge lower seam allowance of right lower front part, press onto wrong side and topstitch. Sew side seams, press seam onto back part.
10. Serge hem of garment. Turn onto wrong side, press and topstitch.

TECHNICAL DRAWING:

