

Sewing Pattern — Jacket 5735

Recommendations on fabric: natural or mixed fabric

You will also need: fusible interfacing; elastic of 0.5 cm width;
3 buttons .

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam allowance: 1 cm for all seams, 3 cm for the hem.

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must match up with corresponding pieces.



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Main fabric:

1. Center upper back – cut 2
2. Center lower back – cut 2
3. Side upper back – cut 2
4. Side lower back – cut 2
5. Back inset – cut 2
6. Center upper front – cut 2
7. Center lower front – cut 2
8. Side upper front – cut 2
9. Side lower front – cut 2
10. Front inset – cut 2
11. Outer collar – cut 1
12. Inner collar – cut 1
13. Sleeve –cut 2
14. Front facing/band – cut 2
15. Back neck facing – cut 1

Fusible interfacing: front facing/bands, back neck facing, outer collar

INSTRUCTIONS:

1. Apply the fusing to wrong side of front band/facing, back neck facing and outer collar.
2. Pin outer collar to inner collar and sew three outer edges, begin and stop stitching at the line of collar joining. Trim corners, turn collar right side out, and press.
3. Sew side upper back to center upper back. Serge and press seam toward center. Sew back inset to upper part, serge and press seam toward inset. Topstitch at 0.1 cm from the joining seam. Sew side lower back to center lower back. Serge and press seam toward center. Sew lower back to inset, serge and press seam toward inset. Topstitch at 0.1 cm from the joining seam.
4. Sew center back seam. Serge and press seam toward left.
5. Sew side upper front to center upper front. Serge and press seam toward center. Make gathering stitches along lower edge of upper center fronts. Sew front inset to upper center fronts, adjusting gathers between marks, serge and press seam toward inset. Topstitch at 0.1 cm from the joining seam. Sew side lower front to center lower front. Serge and press seam toward center. Sew lower front to inset, serge and press seam toward inset. Topstitch at 0.1 cm from the joining seam.
6. Cut a strip of fabric bias tape 3 cm wide for loops. Fold the strip along the center, right sides together, and sew at 0.3 cm from the fold. Trim the seam allowance to 0.5 cm. Turn the strip right side out and press. Cut loop lengths according to button diameter. Tack loops to right front edge as marked.
7. Pin front facing/band to the center front, right sides together, and sew front edge. Sew up to the mark of collar joining. Trim corner seams. Turn front facing/band onto wrong side.
8. Sew shoulder/side seams. Serge and press seam allowances toward back.
9. Sew shoulder edges of back neck facing to front facing/bands, press seams apart. Serge edges. Serge outer edge of facing. Sew inner collar into jacket neckline, sew outer collar to the edge of neckline facing. Trim corners of front facing/bands. Press joining seam allowances apart and tack them close to seams. Sew front facing/band hems to front as marked.
10. Sew sleeve seam, serge and press seam apart. Make a gathering stitch along sleeve cap for ease. Gather sleeve cap slightly. Sew sleeve into armhole, adjusting gathers between marks.
11. Serge bottom edge of sleeve. Press hem allowances onto wrong side and topstitch. Cut a piece of elastic equal to arm girth, sew ends together. Pin equally along top edge of hem and sew with a zigzag stitch, stretching to fit.
12. Serge bottom edge of jacket, press hem allowance to wrong side, then topstitch.
13. Sew buttons on left front edge.

TECHNICAL DRAWING:

