

Sewing Pattern — Draped Jacket 5600

Recommendations on fabric: sheer natural/mixed fabric.

You also need: lining; 1 button.

If the pattern has double contour the seam allowances are included. Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: 1 cm for all seams.

<u>Attention</u>! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

- 1. Center back part 2 pieces
- 2. Side back part 2 pieces
- 3. Center lower front part 2 pieces
- 4. Side lower front part 2 pieces
- 5. Upper font part 2 pieces

Lining:

- 1. Center back part 2 pieces
- 2. Side back part 2 pieces
- 3. Center lower front part 2 pieces
- 4. Side lower front part 2 pieces
- 5. Upper front part 2 pieces

INSTRUCTIONS:

1. Stitch center lower front part to side lower front part. Neaten the seam and press it towards the center.

2. Stitch upper front part to center front part and lower front part. Slash the seam, neaten it and press



upwards.

3. Stitch back relieves and neaten them. Press relieves towards back center. Stitch middle back seam and neaten it. Press middle back seam.

4. Stitch side edges. Neaten seams and press them backwards.

5. Stitch lining details excluding shoulder edge.

6. Lay the lining and the fabric right sides together. Overstitch armholes, back neckline and upper front part along three sides. Slash seams of neckline armholes as well as a corner into slash into upper front part. Turn details right side out and press.

7. Insert front shoulder edge into back shoulder seam between the lining and the fabric. Stitch details together with the same seam. Turn details right side out and press them.

8. Cut fabric stripe of 3 cm width for s loop. Fold the stripe along the center and topstitch at 0.5 cm from bending overstitching one end. Turn the stripe right side out and press it. Cut a loop of necessary length and tack it to right front edging.

9. Overstitch the jacket along both sides at lower edge: between the seam joining upper front part and back relieve. Slash the seam, turn the jacket right side out and press it. Press center back part's lower edge into wrong side. Stitch the lining to upper back part making stitch on jacket's right side at 0.1 cm from edge.

10. Gather the fabric into upper front part on decorative bend according to the sketch. Sew the button on wrong side.

TECHNICAL DRAWING:

