

Sewing Pattern — Dress 5574

Recommendations on fabric: silk/viscose

You will also need: fusing; 7 buttons.

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: 1 cm for all seams, 3 cm for garment hem, 2 cm for sleeve hems

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

- 1. Back part 2 pieces
- 2. Front part 1 piece
- 3. Sleeve 2 pieces

INSTRUCTIONS:

- 1. Stitch bust darts, press darts downwards.
- 2. Stitch waist front darts, press darts toward front center.
- 3. Stitch back darts, press them towards back center.
- 4. Neaten middle back seam. Stitch middle back seam between the hem and closure notch. Press middle seam apart, press closure slit. Stitch the zipper in.
- 5. Neaten shoulder seams, stitch them and press them backwards. Neaten side seams, stitch them and press them backwards.
- 6. Press then piping along the center. Overstitch front/back neckline with the piping. Fold pipings' back ends under and sew by hand.



- 7. Stitch sleeve edges. Neaten sleeve seams and press them.
- 8. Stitch sleeves in easing them along sleeve caps. Neaten joining seams.
- 9. Neaten dress/sleeve hems' allowances, fold them into wrong side and topstitch along edges.

TECHNICAL DRAWING:

