

## Sewing Pattern — Skirt 5457

Recommendations on fabric: sheer viscose or silk.

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: 1 cm for all seams

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



### **CUTTING:**

Fabric:

1. Back panel – 1 piece
2. Right front panel – 1 piece
3. Left front panel – 1 piece
4. Front facing – 1 piece
5. Back facing – 1 piece
6. Back flounce – 1 piece
7. Right front flounce – 1 piece
8. Left front flounce – 1 piece

Fusing: front/back facings.

### **INSTRUCTIONS:**

1. Apply the fusing to wrong side of front/back facings.
2. Sew front/back darts. Press back darts towards back panel center. Press front darts towards front panel center.
3. Neaten from edge of right front flounce and left front flounce. Press right/left front flounce allowance

to wrong side and topstitch at 0.5 cm from edge. Sew right flounce to right front panel. Sew left flounce to left front panel. Neaten joining seam and press it toward the garment.

4. Sew back flounce to back panel. Neaten joining seam and press it toward the garment.

5. Neaten front edge of right front panel and left front panel. Sew right front panel and left front panel together and press joining seam apart. Topstitch seam allowance at 0.7 cm. Pull the cord in and fix it with horizontal stitch of 1 cm.

6. Neaten side edges of front/back panel. Sew garment side seams and press them apart, leaving closure slit in left seam.

7. Sew facings right side edge and press the seam apart. Neaten facing outer edge.

8. Sew the zipper in. Overstitch upper edge of front/back panels with facing. Topstitch oversteitching allowance on facing at 0.2 cm from oversteitching. Fold facing side edges under and sew by hand.

9. Neaten flounce lower edge. Press allowance to wrong side and topstitch on the garment at 0.5 cm from lower edge.

### **TECHNICAL DRAWING:**

