Dress With High Cuffs - Выкройка #2039



Recommendations on fabric: natural/mixed fabrics with elastane suitable for dresses.

You will also need: knit fusible interfacing; dress zipper; 12 buttons; barbed elastic cord.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment – 2 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

О работе с эластичными тканями:
Детали выкройки из трикотажа стачиваются специальным эластичным швом или швом зигзаг. Припуск на подгибку низа может быть настрочен двойной иглой для сохранения эластичности. Детали также можно стачать при помощи оверлока. При стачивании оверлоком, пожалуйста, обрежьте припуски на швы до ширины 0.6 - 0.8 см.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back – cut 2

2. Front - cut 1 on fold
3. Stand collar – cut 4
4. Sleeve – cut 2
5. Cuff – cut 4

Fusible interfacing:
1. Stand collar – cut 2
2. Cuff – cut 2

Инструкции:

1. Apply fusible interfacing.

2. Sew darts on back, press bulk towards center.

3. Sew front darts, press bulk towards top. Sew waist darts on front, press bulk towards center.

4. Sew shoulder and side seams, press towards the back and serge.

5. Pin together parts of stand collar, right sides together and sew along upper and center edge of the Front, start and stop stitching exactly at the seam line of collar stand. Clip into curves, trim away corners, turn stand collar right side out, press. Sew outer stand collar into neckline. Clip into seam allowance of front neckline and press seam allowances at stand collar.

6. Serge center back edges separately. Sew center back seam from notch for zipper down to notch for slit. Press apart center seam. Sew in zipper. Topstitch seam allowances of the slit at 0.2 cm from the edge. Turn under the unfinished edge of inner stand collar and stitch in the ditch. Slipstitch center edges of inner back stand collar to zipper tape.
7. Sew a gathering stitch along upper part of sleeve cap and gather fullness. Sew a gathering stitch along lower edge of sleeve and gather fullness. Serge the sleeve edges separately. Sew sleeve seam from armhole up to mark for slit, press the seam apart. Topstitch slit at 0.1 cm from fold. Sew sleeves into armholes, serge and press.

8. Cut boarded elastic cord into pieces. The number of pieces equals the number of buttons. Make and sew on loop buttonholes onto the right side of outer cuff. Pin cuffs together, right sides together and sew side and lower edges. Start and stop stitching exactly at the marked line of the cuff seam. Turn the piece right side out, press. Sew outer side of cuff to sleeve, fold the seam allowance of the inner cuff inward and stitch in the seam attaching the outer cuff.

9. Serge the lower edge of garment, press onto wrong side and topstitch.

10. Sew on buttons onto cuffs according to markings.

Технический рисунок:

