Jacket - Выкройка #2055



Recommendations on fabric: natural/mixed suiting fabric.

You will also need: fusible interfacing; lining; shoulder pads; 2 buttons; 1 inner button.

Seam allowances: all seams 1 cm. Seam allowance for hem of back – 4 cm, seam allowance on lower edge of sleeve – 3 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back – cut 2
2. Front – cut 2
3. Collar - cut 2
4. Center front facing – cut 2
5. Back neck facing – cut 1
6. Upper sleeve – cut 2
7. Lower sleeve – cut 2

Fusible interfacing:
1. Center front facing – cut 2
2. Back neck facing – cut 1
3. Collar - cut 1

Lining:
1. Back – cut 2
2. Front – cut 2
3. Upper sleeve – cut 2
4. Lower sleeve – cut 2

Инструкции:

1. Apply fusible interfacing. Apply fusing on front along the lapel fold , its width should equal 1 cm (fusible interfacing).

2. Sew darts on back, press bulk towards center. Sew and press apart center back seam.

3. Sew darts on front. Press bulk towards top.

4. Sew and press apart shoulder edges of jacket.

5. Pin upper collar to lower collar and sew the corners and the outer edge. Start and stop sewing exactly at the marked line of the seam between collar and garment. Clip into curves, snip into seam allowance near the mark. Turn the collar right side out, straighten and press.

6. Sew and press apart the shoulder edges of the back neckline facing and of the center front facing.

7. Place center front facing onto front right sides together, pin together and sew along the center front edge. Sew upwards up to the notch marking the end of collar seam. Trim seam allowances at curves. Topstitch seam allowance along center front edge onto center front facing along the closure, and onto front along the part, which is folded away. Place stitch line at 0,2 cm from seam. Turn center front facings right side out, straighten seams.

8. Sew lower collar into neckline of jacket, sew upper collar into neckline of back facing and center front facing, snipping into corner. Snip into seam allowances of collar, press apart and slipstitch together close to the seam.

9. Fold the center front facing already sewn down near the side seam and sew side seams. Press seam allowance of the back towards top.

10. Sew elbow seam on sleeve. Press the seam apart. Seam allowance for hem press. Sew front seam on sleeve. Press the seam apart. Sew sleeves into armholes. Press seam.

11. Sew the pieces from lining, leaving an opening in left elbow seam. Sew lining to back neckline facing, center front facing and hem of the back. Sew lining to hem of sleeve. Turn jacket right side out through the opening. Sew the opening closed.

12. Make buttonholes and sew on buttons. Sew on inner button.

Технический рисунок:

