Jacket With Shortened Sleeve - Выкройка #2077



Recommendations on fabric: natural/mixed suiting fabric.

You will also need: fusible interfacing; lining; 6 buttons; shoulder pads, sleeve heads.

Seam allowances: all seams 1 cm. Seam allowance along hem of jacket and hem of sleeve - 3 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Center back – cut 2
2. Side back – cut 2
3. Center front – cut 2
4. Side front – cut 2
5. Collar – cut 2
6. Sleeve – cut 2
7. Back neck facing – cut 1

8. Center front facing – cut 2
9. Pocket – cut 2

Lining:
1. Center back – cut 2
2. Side back – cut 2
3. Center front – cut 2
4. Side front – cut 2
5. Sleeve – cut 2

Fusible interfacing:
1. Center front – cut 2
2. Back neck facing – cut 1
3. Center front facing – cut 2
4. Collar – cut 1

Attention: Front and back from lining are cut using the pattern blocks for self fabric, with the exception for the areas of center front facing and back neckline facing.

Инструкции:

1. Apply fusible interfacing. Also apply fusible interfacing to seam allowances along hem of garment and hem of sleeve. Apply fusible interfacing to upper edge of pocket.

2. Sew center back seam. Press the seam apart. Sew side backs to center back, press towards center.

3. Sew side fronts to front, press towards center.

4. Serge side and lower edges of pocket. Fold under upper seam allowance of pocket, two times by 1 cm, and topstitch. Fold inside side and lower seam allowances inside and press. Pin pockets onto fronts according to markings and topstitch.

5. Sew the shoulder edges and the side edges, press the seam apart of jacket.

6. Pin collars together right sides together and sew collar ends and the outer edge of collar. Clip into curves, trim away corners. Turn collar right side out, straighten, press. Sew collar into neckline.

7. Sew side seams of back neckline facing and central front facings, press seam apart. Pin facings and center front facings to front right sides together and sew center front edge and neckline. Trim away corners, clip into curves. Fold the center front facings onto right side, straighten seams, press.

8. Sew and press the sleeve seam apart. Sew sleeves into armholes matching notches, adjusting ease on sleeve cap. Sew shoulder pads, sew sleeve heads.

9. Sew seams on lining and sew in sleeves, leaving an opening in left front sleeve seam. Sew lining to inner edges of the center front facings and to the facing. Press lower edge of garment onto wrong side. Sew lining to hem of garment and hem of sleeve. Turn jacket right side out through the opening. Sew the opening closed.

10. Make buttonholes on right front, and sew on buttons onto left front.

Технический рисунок:

