Blouse With Slanted Yoke - Выкройка #2131

Recommendations on fabric: natural/mixed fabrics suitable for blouses.



You will also need: fusible interfacing; 5 buttons.

Seam allowances: Seam allowance for hem of garment – 2 cm; other seams – 1 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back - cut 2
2. Back yoke - cut 2
3. Front - cut 2
4. Front yoke - cut 2
5. Collar – cut 2
6. Placket – cut 4

Fusible interfacing:
1. Placket — cut 2
2. Collar – cut 1

Инструкции:

1. Apply fusible interfacing to plackets and collar.

2. Sew center back seam. Serge seam and press towards left. Sew back yokes to back. Serge the seam allowances and press towards yokes.

3. Sew darts on front. Press bulk towards top. Sew front yokes to front. Serge the seam allowances and press towards yokes.

4. Sew shoulder seams. Serge seams and press towards back.

5. Pin collars together right sides together and sew the outer edge and corner.Start and stop stitching exactly at the marked line .

6. Pin together plackets right sides together and sew center front facings and upper corners. Clip seam allowances, turn right side out and press.
Sew collar to placket along the lapel line. Press the seam apart.

7. Sew outer plackets and collars to the front and to the back. Fold under the seam allowances of inner pieces and topstitch into seam of. Press plackets and collar.

8. Serge side edges separately. Sew side seams from the armhole up to the notch for slit. Press the seam apart. Sew a fastening stitch along the slit at 0.5 cm from the edge.

9. Cut (or take ready) bias tape, its width should equal 4 cm and length should equal the length of armhole + 6 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape onto armhole edge from the right side, leaving loose ends, and sew. Fold bias tape onto wrong side, clip into seam allowances and topstitch onto main piece along the fold. Press seam.

10. Serge the lower edge of garment, turn inside and topstitch.

11. Make buttonholes and sew on buttons on plackets.

Технический рисунок:



