Three-Colour Dress - Выкройка #2135



Recommendations on fabric: natural/mixed knit fabric of medium stretchiness.

You will also need: knit fusible interfacing.

Seam allowances: all seams 1 cm. Seam allowance along hem of dress – 3.0 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

О работе с эластичными тканями:
Детали выкройки из трикотажа стачиваются специальным эластичным швом или швом зигзаг. Припуск на подгибку низа может быть настрочен двойной иглой для сохранения эластичности. Детали также можно стачать при помощи оверлока. При стачивании оверлоком, пожалуйста, обрежьте припуски на швы до ширины 0.6 - 0.8 см.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Lower front – cut 1
2. Lower back – cut 2

Main fabric 1:
1. Back neck facing - cut 2
2. Front neck facing - cut 2
3. Front belt – cut 4
4. Back belt – cut 1

Main fabric 2:
1. Upper back – cut 2
2. Upper front - cut 1 on fold

Fusible interfacing:
1. Back neck facing – cut 1
2. Front neck facing – cut 1

Инструкции:

1. Apply fusible interfacing.

2. Sew darts on back. Press bulk towards center. Sew center back seam on upper backs and lower backs. Serge the seam allowances and press towards left. Sew back belt to upper back and to lower back. Serge the seam allowances and press towards belt.

3. Sew front darts. Press bulk towards top.

4. Sew upper front to lower front. Serge and press towards top.

5. Pin together front neckline facings, right sides together and sew neckline and shoulder edges. Turn the facing onto the right side and press. Finish the back facing in the same way. Sew front facing to back facing, folding them apart onto two sides. Sew front facing to upper front, serge and press onto front. Sew back facing to back, serge and press towards back.

6. Cut (or take ready) bias tape, its width should equal 4 cm and length should equal the length of armhole + 6 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape onto armhole edge from the right side, leaving loose ends, and sew. Fold bias tape onto wrong side, clip into seam allowances and topstitch onto main piece along the fold. Press seam.

7. Pin front belts together pairwise and sew around the long edges, and the slanted edge. Trim seam allowances, turn right side out and press.

8. Sew side seams, inserting front belts according to markings. Press seams towards back and serge.

9. Serge the lower edge of dress, press onto wrong side and topstitch.

Технический рисунок:

