Dress With One-Piece Sleeve - Выкройка #2146

Recommendations on fabric: natural/mixed fabric suitable for dresses.



You will also need: fusible interfacing; 6 buttons; decorative buckle.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment – 3 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back - cut 1 on fold
2. Front - cut 2
3. Center front facing - cut 2
4. Collar - cut 2
5. Cuff – cut 2
6. Back neck facing – cut 1
7. Belt – cut 1

Fusible interfacing:
1. Center front facing - cut 2
2. Collar - cut 1
3. Back neck facing – cut 1

Инструкции:

1. Apply fusible interfacing.

2. Sew side and shoulder seams, press towards the back and serge.

3. Pin collars together, right sides together, and sew collar ends and collar fall. Start and stop sewing exactly at the marked line of the seam between collar and garment. Trim away corners, snip into seam allowance near the mark. Turn the collar right side out, straighten and press.

4. Sew shoulder edges of center front facings and back neckline facing, press the seam apart. Serge the outer edge.

5. Place center front facing onto front right sides together, pin together and sew the lower corner, along the center front edge and the lapel edge. Sew upwards up to the notch marking the end of collar seam. Trim away corners. Turn center front facings right side out, straighten seams.

6. Sew the lower collar into the neckline of the garment, sew upper collar into the neckline of the back neckline facing and of the center front facing. Press apart seam allowances of collars and baste together close to seam.

7. Sew cuff into a ring, press the seam apart. Fold cuff in half lengthwise right side out. Sew cuff to wrong side of sleeve, serge. Fold cuff to right side.

8. Press lower edge of garment onto wrong side at 1 cm, then again at 2 cm and topstitch.

9. Make buttonholes on right front, sew on buttons onto left front. Sew on decorative buttons on right front.

10. Fold belt in half lengthwise right sides together and sew along longer and one shorter sides. Turn belt right side out, straighten, press. Serge the shorter side. Sew a decorative stitch around the contour at 0.1 cm. Thread in and fix buckle on the serged side of the belt.

Технический рисунок:

