Dress With Pleats And Pockets - Выкройка #2160

Recommendations on fabric: natural/mixed fabric suitable for dresses.



You will also need: fusible interfacing.

Seam allowances: all seam allowances – 1.0 cm, seam allowance for hem of garment and hem of sleeve – 2 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back – cut 1 on fold
2. Center front – cut 1 on fold
3. Side front – cut 2
4. Front yoke – cut 2
5. Inset – cut 2
6. Pocket bag – cut 2
7. Sleeve – cut 2

8. Back neck facing – cut 1

Main fabric:
1. Back neck facing – cut 1

Инструкции:

1. Apply fusible interfacing.

2. Pin front yokes together, right sides together and sew the neckline opening. Clip seam allowances, turn right side out yokes onto right side, straighten and press.

3. Fold the center front, wrong sides together, and stitch the pleats up to the marked horizontal lines. Press bulk towards center.

4. Sew pocket bag to center front according to notches, serge. Sew side front to front, sewing seam allowances of pocket bags at the same time. Press seams towards center and serge.

5. Sew outer yoke to front, press seam allowances towards yoke. Fold under the seam allowance of the lower edge of the inner yoke, press, and stitch in the ditch into the seam of the outer yoke.

6. Serge outer edge of back neckline facing. Pin neckline facing onto Back and sew neckline exactly up to the marked line of shoulder seam. Clip seam allowances, fold facing onto wrong side and press.

7. Sew shoulder seams, inserting Front between Back and back neckline facing. Press seams towards back and serge.

8. Sew inset to back, press seam allowances towards inset and serge. Sew inset to front, sewing the side seam at the same time, press seam allowances towards inset and serge.

9. Sew sleeve seams, press towards the back and serge. Sew sleeves into armholes, serge and press.

10. Serge lower edge of garment and lower edge of sleeve, press onto wrong side and topstitch.

Технический рисунок:

