# Dress - Выкройка #2164

Recommendations on fabric: soft natural/mixed fabric suitable for dresses.



You will also need: dress zipper; 5 buttons; elastic tape, its width should equal 1 cm.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve – 2 cm.

**О припусках на швы::**
*- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.*
*- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.*

**О требуемой длине ткани:**
*Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.*

## РАСКРОЙ:

**Обратите внимание при раскрое:**
*Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.*
*При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.*

Main fabric:
1. Upper back – cut 2
2. Center back – cut 2
3. Side back – cut 2
4. Upper front – cut 1 on fold
5. Center front – cut 1 on fold
6. Side front – cut 2
7. Sleeve – cut 2

## Инструкции:

1. Sew princess seams of lower back (sew side backs to center back), press towards center and serge. Sew upper back to lower part, press towards top and serge.

2. Serge center back edges separately. Sew the center back seam from zipper mark to hem, press the seam apart. Sew in zipper.

3. Sew darts on upper fronts, press the inner part towards center. Sew princess seams on lower front (sew lower side fronts to lower center front), press seams towards center and serge. Sew upper front to lower front, press towards top and serge.

4. Sew shoulder seams, press towards the back and serge.

5. Cut or use ready-made bias tape, its width should equal 4 cm and length should equal the length of neckline + 5 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape to neckline from the right side and sew. Clip into seam allowances. Fold bias tape onto wrong side and topstitch onto main piece along the fold. Press seam. Slipstitch the ends of the bias tape to zipper tape.

6. Cut two ties on bias, 2.5 wide and 50 cm long. Fold tape in half lengthwise right sides together and stitch at 0.5 cm from fold. Turn the tie right side out and straighten it. Turn under one of the ends and stitch.

7. Sew side seams, inserting the ties, press towards the back and serge.

8. Sew sleeve seam, serge and press. Sew a gathering stitch along the sleeve cap and gather fullness. Serge lower edge of sleeve, press onto wrong side and topstitch.

9. Cut a piece of elastic tape, the length should equal the overarm girth at the biceps area. Sew it into a ring. Topstitch the elastic tape onto the sleeve along the marked line, from the wrong side.

10. Sew sleeves into armholes, serge and press.

11. Serge hem of garment, press onto wrong side and topstitch.

12. Sew on decorative buttons onto upper front.

## Технический рисунок:

