Blouse With Central Placket - Выкройка #2186

Recommendations on fabric: thick natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing; 8 buttons.

Seam allowances: Seam allowance along hem of garment – 1.5 cm. Other seams – 1.0 cm



О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back yoke - cut 1 on fold
2. Back - cut 1 on fold
3. Front – cut 1 on fold
4. Placket – cut 2
5. Collar - cut 2
6. Stand collar - cut 2
7. Sleeve - cut 2

8. Cuff - cut 2

Fusible interfacing:
1. Placket – cut 2
2. Collar - cut 1
3. Stand collar - cut 1
4. Cuff – cut 2

Инструкции:

1. Apply fusible interfacing.

2. Make and baste a box pleat on the upper edge of Back. Sew yoke to back, press towards top and serge.

3. Sew front darts, press bulk towards top.

4. Sew a gathering stitch along the short horizontal edge on Front and gather fullness. Press plackets in half lengthwise right side out. Make buttonholes on right placket. Sew plackets to right side of front along longer edge, stop at 1 cm from the bottom. Snip into seam allowance on front, leaving 1 mm to the stitch line. Thread the ends of plackets inside and sew, fastening the lower edge. Serge the seam allowances.

5. Sew shoulder and side seams, press towards the back and serge.

6. Pin together collars right sides together sew collar ends and the outer edge of collar. Trim away corners, turn collar right side out, straighten, press. Pin together parts of stand collar, right sides together and sew along the outer edge, inserting collar. Start and stop sewing exactly at the marked line of seam between stand collar and garment. Trim seam allowances, stand collar turn right side out and press.

7. Sew outer stand collar with collar into neckline, fold inside open edge of internal stand collar and stitch in the ditch.

8. Serge the sleeve edges separately. Sew sleeve seam form the mark upwards, press the seam apart. Sew a fastening stitch along the slit at 0.1 cm from the edge. Sew sleeves into armholes, serge and press.

9. Fold cuff in half lengthwise, right sides together and sew side seams. Turn the piece right side out, press. Sew outer side of cuff to sleeve, fold the seam allowance of the inner cuff inward and stitch in the seam attaching the outer cuff.

10. Serge lower edge of garment, press onto wrong side and topstitch.

11. Make button holes and sew on buttons on stand collar and cuffs. Sew on buttons on left front.

Технический рисунок:

