Blouse With Gathers - Выкройка #2192

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing.

Seam allowances: seam allowance for hem of garment and hem of sleeve – 2.5 cm, other seams 1 cm.



О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back – cut 1 on fold
2. Front yoke – cut 2
3. Front — cut 1 on fold
4. Sleeve – cut 2
5. Back neck facing — cut 1
6. Front neck facing — cut 2

Fusible interfacing:
1. Back neck facing — cut 1
2. Front neck facing — cut 2

Инструкции:

1. Apply fusible interfacing to the neckline facings and to the one-piece center front facing of front yoke.

2. Sew shoulder seams, press towards the back and serge.

3. Sew the shoulder seams of the neckline facings, press the seam apart. Serge the outer edge. Serge the vertical edge of the one-piece center front facing of the front yoke. Sew the facing to the edges of center front facing. Fold the center front facing and the facing onto the right side and sew the neckline. Fold the facing onto the wrong side, straighten, press. Pin yokes together, right sides together inside and sew the center seam from bottom to the mark, press the seam apart. Topstitch center front facing into the main piece along the inner edge, topstitch facing at 0.5-0.7 cm from the neckline edge.

4. Sew a gathering stitch along upper edge of front and gather fullness. Sew front yoke to front, press towards top and serge.

5. Sew side seams, press towards the back and serge.

6. Sew sleeve seam, serge and press. Sew sleeves into armholes, serge and press.

7. Press lower edge of garment and lower edge of sleeve onto wrong side at 1 cm, then at 1.5 cm and topstitch.

Технический рисунок:

