Blouse With Scalloped Neckline - Выкройка #2201

Recommendations on fabric: natural/mixed fabrics suitable for blouses, lace with scallops.

You will also need: fusible interfacing, 5 buttons.



Seam allowances: seam allowance for hem of garment — 2.0 cm, other seams - 1 cm, seam allowance on lower edge of sleeve – 0 cm. When cutting the sleeve, place the pattern block so that the scalloped edge of the fabric is along the sleeve hem.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back – cut 1 on fold
2. Front — cut 2
3. Center front facing — cut 2
4. Back neck facing – cut 1

Lace:

1. Sleeve — cut 2

Fusible interfacing:
1. Center front facing — cut 2
2. Back neck facing – cut 1

Инструкции:

1. Apply fusible interfacing.

2. Sew darts on front. Press bulk towards top.

3. Sew side and shoulder seams, press towards the back and serge.

4. Sew and press apart the shoulder edges of the back neckline facing and of the center front facing. Serge the outer edge.

5. Place center front facing onto front right sides together, pin together and sew the lower corner, along the center front edge and neckline. Trim seam allowances, clip into corners and along neckline. Turn center front facings right side out, straighten seams.

6. Sew sleeve seam, press towards the back and serge. Sew sleeves into armholes, matching notches. Serge and press.

7. Serge the lower edge of garment, press onto wrong side and topstitch.

8. Make buttonholes on right front, sew on buttons onto left front.

Технический рисунок:

