Dress With Pockets In French Darts - Выкройка #2209



Recommendations on fabric: natural/mixed fabric suitable for dresses.

You will also need: fusible interfacing; dress zipper.

Seam allowances: Seam allowance along hem of garment and hem of sleeve – 2.0 cm. Other seams – 1.0 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back - cut 2
2. Front - cut 1 on fold
3. Front neck facing - cut 1
4. Back neck facing - cut 2
5. Pocket bag – cut 4

Fusible interfacing:

1. Front neck facing - cut 1
2. Back neck facing - cut 2

Инструкции:

1. Apply fusible interfacing. Also apply fusible interfacing to the seam allowance of lower pocket bag on Front.

2. Sew darts on back, press the inner part towards center. Serge the center back edges separately, sew them from notch for zipper to bottom, press the seam apart. Sew in zipper.

3. Clip into seam allowances near the notch for pocket. Sew pocket bags to front. Serge the seam allowances. Sew side front to front, sewing the pocket bag at the same time. Serge.

4. Sew shoulder and side seams. Serge seams and press towards back.

5. Sew the shoulder seams of the neckline facings, press the seam apart. Serge the outer edge. Pin facing onto dress, right side down and sew the neckline. Clip seam allowances, fold facing onto wrong side and press. Slipstitch facing to zipper tape.

6. Sew sleeve seam. Serge and press towards back. Sew sleeve into armhole according to notches, serge and press.

7. Serge hem of garment and hem of sleeve, press onto wrong side and topstitch.

Технический рисунок:

