Dress With Elastic Waistband - Выкройка #2297

Recommendations on fabric: natural/mixed fabric suitable for dresses.



You will also need: elastic tape, its width should equal 1.0 cm, decorative cord; 1 button.

Seam allowances: seam allowance for hem of garment — 2 cm, Seam allowance of sleeve hem – 1.5 cm; other seams 1 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back – cut 2
2. Front — cut 1 on fold
3. Casing — cut 1
4. Neckline facing — cut 1

Fusible interfacing:
1. Neckline facing – cut 1

Инструкции:

1. Apply fusible interfacing to the facing горловины. Also apply fusible interfacing to the area on front where button holes will be made.

2. Serge center back edges separately. Sew backs from the marking for slit down to the lower edge. Press the seam allowances apart.

3. Make buttonholes on front under cord.

4. Sew shoulder seams. Serge seams and press towards back.

5. Sew side seams processing the sleeve seam at the same time. Serge seams and press towards back.

6. Turn under seam allowances around all edges of the casing and press. Pin casing onto the back side of the dress, the edges meet near left side seam. Topstitch casing onto dress. Sew horizontal stitch lines according to the markings.

7. Cut (or take ready) bias tape, its width should equal 2.5 cm and its length should equal 5 cm for loop buttonhole. Fold tape in half lengthwise right sides together and stitch at 0.3 cm from fold. Cut away seam allowances close to seam, turn tape right side out and straighten the rolled piece. Adjust length of the loop.

8. Serge the outer edge facings. Pin facing onto neckline right side down and sew neckline. Clip into seam allowance, turn facing onto wrong side and press. Slipstitch center edges of the back to the seam allowances on the back, inserting the loop buttonhole.

9. Serge hem of garment and lower edge of sleeve, press onto wrong side and topstitch.

10. Thread in elastic tape into casing and sew ends. Thread in decorative cord.

11. Sew on a button.

Технический рисунок:

