Blouse With Asymmetrical Pleats - Выкройка #2314

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing; 3 buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment – 2 cm.



О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back yoke – cut 1
2. Back – cut 1 on fold
3. Front - cut 1
4. Stand collar – cut 2
5. Sleeve – cut 2
6. Cuff – cut 2

Fusible interfacing:
1. Stand collar – cut 1
2. Cuff – cut 2

Инструкции:

1. Apply fusible interfacing.

2. Make and baste a box pleat on Back. Sew yoke to back, press towards top and serge.

3. Mark the line of slit on Front (mark with circle), slash. Cut (or take ready) a bias tape for finishing slit on Front, its length should equal the double length of slit + 4 cm and , its width should equal 5 cm. Press bias tape in half lengthwise right side out. Lay the front flat, aligning the slit into a straight line, pin the bias tape from the right side, matching edges, and sew. Width of seam along the slit 0.5 – 0.7 cm, decrease it to 0.2 cm in the lower part of the slit. Fold bias tape onto wrong side, wrapping the seam, and topstitch into seam of.

3. Sew the bust dart, press bulk towards top. Make and baste pleats on front (fold the bulk away from the center).

4. Sew shoulder and side seams, press towards the back and serge.

5. Pin together parts of stand collar, right sides together and sew along outer edge and ends, start and stop stitching exactly at the seam line of collar stand. Clip into curves, trim away corners, turn stand collar right side out, straighten, press. Sew outer stand collar into neckline, fold inside open edge of internal stand collar and stitch in the ditch.

6. Sew a gathering stitch along lower edge of sleeve and gather fullness. Serge the sleeve edges separately. Sew sleeve seam from armhole up to mark for slit, press the seam apart. Topstitch slit at 0.1 cm from fold. Sew sleeves into armholes, serge and press.

7. Pin cuffs together, right sides together and sew side edges. Start and stop stitching exactly at the marked line of the cuff seam. Turn the piece right side out, press. Sew outer side of cuff to sleeve, fold the seam allowance of the inner cuff inward and stitch in the seam attaching the outer cuff.

8. Press lower edge of garment onto wrong side two times at 1 cm and topstitch.

9. Make a buttonhole and sew on button on stand collar. Make buttonholes on cuffs, sew on buttons.

Технический рисунок:

