Dress With Shaped Hem - Выкройка #2321

Recommendations on fabric: natural/mixed fabric suitable for dresses.

You will also need: fusible interfacing; 8 buttons.

Seam allowances: Seam allowance for hem of garment – 1.5 cm, other seams – 1 cm.



О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:

1. Back yoke - cut 1 on fold
2. Back - cut 2
3. Front - cut 2
4. Front yoke – cut 2
5. Collar – cut 2
6. Stand collar – cut 2
7. Belt – cut 1
8. Placket – cut 2
9. Cuff – cut 2

Fusible interfacing:
1. Placket – cut 2
2. Collar – cut 1
3. Stand collar – cut 1

Инструкции:

1. Apply fusible interfacing.

2. Sew center back seam. Serge seam and press towards left. Sew back yoke to back. Serge and press towards top.

3. Sew front yoke to front. Serge and press towards top. Sew center front seam. Serge seam and press towards left.

4. Fold the plackets in half lengthwise, wrong sides together and press. Sew plackets to front along the longer edge. Slash into corner of seam allowance of lower front. Pin right placket onto left placket, sew the lower edge to lower front from the wrong side. Serge seam allowances plackets around all edges.

5. Serge the lower edge of garment, turn inside and topstitch.

6. Sew side seams processing the sleeve seam at the same time. Press seams towards back and serge. Sew shoulder seams, press towards the back and serge.

7. Pin upper collar to lower collar, right sides together. Sew ends of collar and collar fall. Trim seam allowances. Turn the collar right side out, straighten and press. Sew a decorative stitch at 0.5 cm from the edge. Pin stand collars together, right sides together, put ready collar between them, adjust notches and sew, sewing ends of stand collar at the same time. Start and stop sewing exactly at the marked line of seam between stand collar and garment. Turn finished collar right side out and press. Sew upper stand collar with collar into neckline, fold raw edge of lower stand collar and stitch-in-the-ditch along seam of upper stand collar.

8. Sew cuff seam, press the seam allowances apart. Fold cuff into a ring right side out and press. Sew cuff to wrong side of sleeve. Serge. Fold cuff to right side and slipstitch it to shoulder seam.

9. Make button holes on the right placket and the right stand collar, sew on buttons on the left one.

10. Fold belt in half lengthwise right sides together and sew along one longer and two shorter sides, leaving an opening for turning. Trim away corners, belt turn right side out and press.

Технический рисунок:

